

UG87-LW

Industrial LoRaWAN Gateway User Guide

Ursalink Technology Co., Ltd.



Preface

Thanks for choosing Ursalink UG87-LW industrial LoRaWAN gateway. The UG87-LW industrial LoRaWAN gateway delivers tenacious connection over network with full-featured design such as automated failover/failback, extended operating temperature, dual SIM cards, hardware watchdog, VPN, Gigabit Ethernet and beyond.

This guide shows you how to configure and operate the UG87-LW industrial LoRaWAN gateway. You can refer to it for detailed functionality and gateway configuration.

Readers

This guide is mainly intended for the following users:

- Network Planners
- On-site technical support and maintenance personnel
- Network administrators responsible for network configuration and maintenance

© 2017 Xiamen Ursalink Technology Co., Ltd.

All rights reserved.

All information in this user guide is protected by copyright law. Whereby, no organization or individual shall copy or reproduce the whole or part of this user guide by any means without written authorization from Xiamen Ursalink Technology Co., Ltd.

Products Covered

This guide explains how to configure the following devices:


- Ursalink UG87-LW LoRaWAN gateway

Related Documents

Document	Description
Ursalink UG87-LW Datasheet	Datasheet for the Ursalink UG87-LW industrial LoRaWAN Gateway.
Ursalink UG87-LW Quick Start Guide	Quick installation guide for the Ursalink UG87-LW industrial LoRaWAN Gateway.

Declaration of Conformity

UG87-LW is in conformity with the essential requirements and other relevant provisions of the CE, FCC, and RoHS.



For assistance, please contact
 Ursalink technical support:
 Email: support@ursalink.com
 Tel.: 86-592-5023060
 Fax: 86-592-5023065

Revision History

Date	Doc Version	Description
Jul. 19, 2018	V.1.0.0	Initial version

Contents

Chapter 1 Product Introduction.....	8
1.1 Overview.....	8
1.2 Advantages.....	8
1.3 Specifications.....	10
Chapter 2 Installation.....	13
2.1 General Packing List.....	13
2.2 Product Overview.....	14
2.3 LED Indicators.....	15
2.4 Ethernet Port Indicators.....	15
2.5 Reset Button.....	16
2.6 PIN Definition.....	16
2.7 SIM Card Installation.....	16
2.8 Cellular Antenna Installation.....	17
2.9 Mounting the Gateway.....	18
2.10 Connect the Gateway to a Computer.....	19
2.11 Installation of Power Supply and Protective Grounding.....	19
2.11.1 Power Supply Installation.....	19
2.11.2 Protective Grounding Installation.....	19
Chapter 3 Access to Web GUI.....	21
3.1 PC Configuration for Web GUI Access to gateway.....	21
3.2 Access to Web GUI of gateway.....	22
Chapter 4 Web Configuration.....	24
4.1 Status.....	24
4.1.1 Overview.....	24
4.1.2 LoRa WAN.....	25
4.1.3 Cellular.....	27
4.1.4 Network.....	29
4.1.5 VPN.....	30
4.1.6 Routing Information.....	31
4.1.7 Host List.....	32
4.2 LoRa.....	33
4.2.1 Packet Forwarder.....	33
4.2.1.1 General.....	33
4.2.1.2 Radios.....	34
4.2.1.3 Advanced.....	36
4.2.1.4 Custom.....	38
4.2.1.5 Traffic.....	38
4.2.2 Network Server.....	40
4.2.2.1 General.....	40
4.2.2.2 Application.....	42
4.2.2.3 Profiles.....	42
Related Configuration Example.....	43

4.2.2.4 Device.....	43
4.2.2.5 Packet.....	44
4.3 Network.....	46
4.3.1 Interface.....	46
4.3.1.1 Port.....	46
4.3.1.2 WAN.....	47
4.3.1.3 LAN.....	50
4.3.1.4 VLAN Trunk.....	51
4.3.1.5 Cellular.....	52
4.3.1.6 Loopback.....	55
4.3.2 Firewall.....	56
4.3.2.1 ACL.....	56
4.3.2.2 DMZ.....	57
4.3.2.3 Port Mapping.....	58
4.3.2.4 MAC Binding.....	59
4.3.3 QoS.....	59
4.3.4 DHCP.....	60
4.3.4.1 DHCP Server.....	60
4.3.4.2 DHCP Relay.....	62
4.3.5 DDNS.....	62
4.3.6 Link Failover.....	63
4.3.6.1 SLA.....	63
4.3.6.2 Track.....	64
4.3.6.3 VRRP.....	65
4.3.6.4 WAN Failover.....	66
4.3.7 VPN.....	67
4.3.7.1 DMVPN.....	67
4.3.7.2 IPsec.....	69
4.3.7.3 GRE.....	72
4.3.7.4 L2TP.....	73
4.3.7.5 PPTP.....	75
4.3.7.6 OpenVPN Client.....	77
4.3.7.7 OpenVPN Server.....	78
4.3.7.8 Certifications.....	80
4.4 System.....	82
4.4.1 General Settings.....	82
4.4.1.1 General.....	82
4.4.1.2 Account Management.....	83
4.4.1.3 System Time.....	84
4.4.1.4 SMTP.....	85
4.4.1.5 Phone.....	86
4.4.2 User Management.....	87
4.4.3 SNMP.....	88
4.4.3.1 SNMP.....	88

4.4.3.2 MIB View.....	89
4.4.3.3 VACM.....	89
4.4.3.4 Trap.....	90
4.4.3.5 MIB.....	91
4.4.4 AAA.....	91
4.4.4.1 RADIUS.....	91
4.4.4.2 TACACS+.....	92
4.3.4.3 LDAP.....	92
4.3.4.4 Authentication.....	93
4.3.5 Device Management.....	94
4.3.6 Events.....	95
4.3.6.1 Events.....	95
4.3.6.2 Events Settings.....	96
4.5 Industrial Interface.....	97
4.5.1 I/O.....	98
4.5.1.1 DI.....	98
4.5.1.2 DO.....	99
4.5.2 Serial Port.....	100
4.5.3 Modbus Master.....	103
4.5.3.1 Modbus Master.....	103
4.5.3.2 Channel.....	103
4.6 Maintenance.....	105
4.6.1 Tools.....	105
4.6.1.1 Ping.....	105
4.6.1.2 Traceroute.....	106
4.6.2 Schedule.....	106
4.6.3 Log.....	107
4.5.3.1 System Log.....	107
4.6.3.2 Log Settings.....	108
4.6.4 Upgrade.....	109
4.6.5 Backup and Restore.....	109
4.6.6 Reboot.....	110
4.7 APP.....	111
4.7.1 Python.....	111
4.7.1.1 Python.....	111
4.7.1.2 App Manager Configuration.....	112
4.7.1.3 Python App.....	113
Chapter 5 Application Examples.....	114
5.1 Application configuration.....	114
5.2 Device Profiles configuration.....	115
5.3 Device configuration.....	117
5.4 Account Info Management.....	120
5.5 Common User Management.....	121
5.6 System Time Management.....	122

5.7 Backup and Restore Configuration.....	123
5.8 Restore Factory Defaults.....	124
5.8.1 Via Web Interface.....	124
5.8.2 Via Hardware.....	126
5.9 Firmware Upgrade.....	126
5.10 Events Application Example.....	128
5.11 Schedule Application Example.....	130
5.12 Logs and Diagnostics.....	130
5.13 SNMP Application Example.....	132
5.14 Cellular Connection.....	135
5.15 Dual SIM Backup Application Example.....	137
5.17 NAT Application Example.....	140
5.18 Access Control Application Example.....	140
5.18 DTU Application Example.....	141
5.19 PPTP Application Example.....	145

Chapter 1 Product Introduction

1.1 Overview

Ursalink UG87-LW is an industrial LoRa gateway with embedded intelligent software features that are designed for multifarious M2M/IoT applications. Supporting global WCDMA and 4G LTE, UG87-LW provides drop-in connectivity for operators and makes a giant leap in maximizing uptime.

Adopting high-performance and low-power consumption industrial platform of 64-bit CPU and wireless module, the UG87-LW is capable of providing wire-speed network with a typical 2 W power consumption and ultra-small package to ensure the extremely safe and reliable connection to the wireless network.

Meanwhile, the UG87-LW also supports Gigabit Ethernet port, serial port (RS232), which enables you to scale up M2M application combining data and video in limited time and budget.

The UG87-LW is particularly ideal for smart grid, digital media installations, industrial automation, telemetry equipment, medical device, digital factory, finance, payment device, environment protection, water conservancy and so on.




Figure 1-1

1.2 Advantages

Benefits

- Built-in industrial strong CPU, big memory;
- Dual SIM cards for backup between multiple carriers networking and global 2G/3G/LTE options make it easy to get connected
- Embed Ursalink SDK (Python 2.7/C) for secondary development
- Flexible modular design provides users with different connection modules like Ethernet, serial port for connecting diverse field assets
- Rugged enclosure, optimized for DIN rail or shelf mounting
- 3-year warranty included

Security & Reliability

- Automated failover/failback between Ethernet and Cellular (dual SIM)
- Enable unit with security frameworks like IPsec/OpenVPN/GRE/L2TP/PPTP/ DMVPN
- With embedded hardware watchdog to automatically recover from various failure and ensure highest level of availability
- Establish a secured mechanism on centralized authentication and authorization of device access by supporting AAA (TACACS+, RADIUS, LDAP, local authentication) and multiple levels of user authority

Easy Maintenance

- Ursalink DeviceHub provides easy setup, mass configuration, and centralized management of remote devices
- The user-friendly web interface design and various upgrading options help administrator to manage the device as easy as pie
- WEB GUI and CLI enable the admin to achieve quick configuration and simple management among a large quantity of devices
- Efficiently manage the remote devices on the existing platform through the industrial standard SNMP

Capabilities

- Link remote devices in an environment where communication technologies are constantly changing
- Industrial 64-bit ARM Cortex-A53 processor, high-performance operating up to 800MHz with low power consumption, and 512 MB memory available to support more applications
- Support wide operating temperature ranging from -40°C to 70°C/-40°F to 158°F

1.3 Specifications

Cellular Interfaces	
Connectors	2 × 50 Ω SMA (Center pin: female)
SIM Slots	2
LoRaWAN	
Connectors	1 × 50 Ω SMA (Center pin: female)
Channel	8
Frequency Band	Supports EU 863-870, US 902-928, EU 433, AU 915-928, CN 470-510 and KR 920-923 Band
Sensitivity	-140dBm Sensitivity @292bps
Output Power	27dBm Max
Protocol	V1.0 Class A/Class C and V1.0.2 Class A/Class C
Hardware System	
CPU	800MHz, 64-bit ARM Cortex-A53
Memory	4 GB Flash, 512 MB DDR3 RAM
Ethernet	
Ports	1 × RJ-45
Physical Layer	10/100/1000 Base-T (IEEE 802.3)
Data Rate	10/100/1000 Mbps (auto-sensing)
Interface	Auto MDI/MDIX
Mode	Full or half duplex (auto-sensing)
Serial Interface	
Ports	1 × RS232
Connector	Terminal Block
Baud Rate	300bps to 230400bps
IO	
Connector	(4) pin screw down terminal block
Digital	2 × DI + 2 × DO
Software	
Network Protocols	PPP, PPPOE, SNMP v1/v2c/v3, TCP, UDP, DHCP, DDNS, VRRP, HTTP, HTTPS, DNS, SNTP, Telnet, VLAN, SSH, etc.
VPN Tunnel	DMVPN/IPsec/OpenVPN/PPTP/L2TP/GRE
Access Authentication	CHAP/PAP/MS-CHAP/MS-CHAPV2
Firewall	ACL/DMZ/Port Mapping/MAC Binding

Management	Web, CLI, SMS, On-demand dial up
AAA	RADIUS, TACACS+, LDAP, Local Authentication
Multilevel Authority	Multiple levels of user authority
Reliability	VRRP, Dual SIM Backup
Serial Port	Transparent (TCP Client/Server, UDP), Modbus Gateway (Modbus TCP to Modbus RTU), Modbus Master
Power Supply and Consumption	
Connector	2-pin with 5.08 mm terminal block
Input Voltage	9-48 VDC
Power Consumption	Typical 2.3 W (Max 3.2 W)
Physical Characteristics	
Ingress Protection	IP30
Housing & Weight	Metal, 369 g (0.81 lb)
Dimensions	100 x 96.1 x 30 mm (3.94 x 3.78 x 1.18 in)
Mounting	Desktop, wall or DIN rail mounting
Others	
Reset Button	1 × RESET
LED Indicators	1 × POWER, 1 × STATUS, 1 x LoRa , 1 × VPN, 1 × SIM1, 1 × SIM2, 3 × Signal strength
Built-in	Watchdog, RTC, Timer
Certifications	RoHS, CE, FCC
EMC	IEC 61000-4-2 Level 3 IEC 61000-4-3 Level 4 IEC 61000-4-4 Level 3 IEC 61000-4-5 Level 4 IEC 61000-4-6 Level 3 IEC 61000-4-8 Level 4
Environmental	
Operating Temperature	-40°C to +70°C (-40°F to +158°F) Reduced cellular performance above 60°C
Storage Temperature	-40°C to +85°C (-40°F to +185°F)
Ethernet Isolation	1.5 kV RMS
Relative Humidity	0% to 95% (non-condensing) at 25°C/77°F





Figure 1-2


Chapter 2 Installation

2.1 General Packing List


Before you begin to install the UG87-LW, please check the package contents to verify that you have received the items below.



1 × UR87-LW Gateway



1 × Ethernet Cable




1 × Power Adapter




2 × SIM Card Slots




1 × 2-PIN Pluggable Terminal



1 × 10-PIN Pluggable Terminal



1 × Warranty Card



1 × Quick Start Guide



2 × Magnetic Mount Cellular Antennas (Default)




2 × Stubby Cellular Antennas (Optional)




1 × Stubby LoRa Antennas (Optional)




1 × GPS Antenna



1 × DIN Rail Kit (Default)



2 × Rack Mount Kits (Optional)




1 × Wall Mounting Bracket (Optional)



If any of the above items is missing or damaged, please contact your Ursalink sales representative.


2.2 Product Overview

A. Front Panel



- ① Main Cellular Antenna
- ② Reset Button
- ③ LED Indicator Area
POWER: Power Indicator
STATUS: Status Indicator
↕: Signal Strength Indicator
LORA: LoRa Indicator
VPN: VPN Indicator
SIM1: SIM1 Status Indicator
SIM2: SIM2 Status Indicator
- ④ Ethernet Port Indicator:
Orange for data transmission;
Green for network rate
- ⑤ AUX Cellular Antenna
- ⑥ GPS Antenna
- ⑦ Serial Port & I/O
- ⑧ LoRa Antenna

B. Left Panel



- ① SIM Card Slot
- ② Power Connector
- ③ Grounding Stud

2.3 LED Indicators

LED	Indication	Status	Description
POWER	Power Status	On	The power is switched on
		Off	The power is switched off
STATUS	System Status	Green Light	Static: Start-up
		Green Light	Blinking slowly: the system is running properly
		Off	The system goes wrong
LoRa	LoRa Status	Green Light	Packet Forwarder mode is running well.
		Off	Packet Forwarder mode is running off.
VPN	VPN Status	Green Light	VPN is connected
		Off	VPN is disconnected
SIM1/SIM2	SIM Card Status	Off	SIM1 or SIM2 is registering or fails to register (or there are no SIM cards inserted)
		Green Light	Blinking slowly: SIM1 or SIM2 has been registered and is ready for dial-up
		Green Light	Blinking rapidly: SIM1 or SIM2 has been registered and is dialing up now
		Green Light	Static: SIM1 or SIM2 has been registered and dialed up successfully
Signal Strength	Signal 1/2/3	Off	No signal
		Green Light	Static/Off/Off: weak signals with 1-10 ASU (please check if the antenna is installed correctly, or move the antenna to a suitable location to get better signal)
		Green Light	Static/Static/Off: normal signals with 11-20 ASU (average signal strength)
		Green Light	Static/Static/Static: strong signals with 21-31 ASU (signal is good)


2.4 Ethernet Port Indicators

Indicator	Status	Description
Link Indicator (Orange)	On	Connected
	Blinking	Transmitting data
	Off	Disconnected
Rate Indicator (Green)	On	1000Mbps mode
	off	100Mbps mode


2.5 Reset Button

Function	Description	
	STATUS LED	Action
Reboot	Blinking	Press and hold the reset button for about 5-15 seconds.
	Static Green	Release the button and wait for system to reboot.
Reset	Blinking	Press and hold the reset button for more than 15 seconds.
	Static Green → Rapidly Blinking	Release the button and wait.
	Off → Blinking	The gateway is now reset to factory defaults.

2.6 PIN Definition




PIN	RS232	DI	DO	Description
1	TXD	---	---	Transmit Data
2	RXD	---	---	Receive Data
3	---	---	---	Data +
4	---	---	---	Data -
5	GND	GND	---	Ground
6	---	IN1	---	Digital Input1
7	---	IN2	---	Digital Input2
8	---	---	OUT1	Digital Output1
9	---	---	OUT2	Digital Output2
10	---	---	COM	Common Ground




PIN	Description
11	Positive
12	Negative

2.7 SIM Card Installation

A. Push the yellow button on left panel of the gateway, and then you will see the SIM card slot popping out directly.




B. Put SIM card onto the slot, and then insert the slot back into the hole.



2.8 Cellular Antenna Installation

A. Rotate the antenna into the Antenna Connector.

The external cellular antenna should be installed vertically always on a site with a good cellular signal.



Note: UG87-LW supports dual antennas with “Main” and “AUX” connectors. “Main” interface is for data receiving and transmission. “AUX” interface is for enhancing signal strength, which cannot be used separately.


2.9 Mounting the Gateway

The gateway can be placed on a desktop or mounted to a wall or a DIN rail.

2.9.1 Wall Mounting (Measured in mm)

Use 2 pcs of M3×6 flat head Phillips screws to fix the wall mounting kit to the gateway, and then use 2 pcs of M3 drywall screws to mount the gateway associated with the wall mounting kit on the wall.


! Recommended torque for mounting is 1.0 N. m, and the maximum allowed is 1.2 N.m.




2.9.2 DIN Rail Mounting (Measured in mm)

Use 2 pcs of M3×6 flat head Phillips screws to fix the DIN rail to the gateway, and then hang the DIN rail on the mounting bracket. It is necessary to choose a standard bracket.

! Recommended torque for mounting is 1.0 N. m, and the maximum allowed is 1.2 N.m.




2.10 Connect the Gateway to a Computer



2.11 Installation of Power Supply and Protective Grounding

2.11.1 Power Supply Installation

- A. Take out the terminal from the gateway and unscrew the bolt on terminal.
- B. Screw down the bolt after inserting power cable into the terminal.




Connecting the Power Cable

Color	Polarity
Red	+
Yellow	-

! If you insert wires into the reverse holes, the gateway will not start and you must switch the wires into the correct holes.

2.11.2 Protective Grounding Installation

1. Remove the grounding nut.
2. Connect the grounding ring of the cabinet's grounding wire onto the grounding stud and screw up the grounding nut.





The gateway must be grounded when deployed. According to operating environment, the ground wire should be connected with grounding stud of gateway.

2.12 Examine

1. Double check antenna connection.
2. Double check if SIM card is correctly inserted and working perfectly.
3. Power on the UG87-LW industrial LoRaWAN gateway and check indicators status.
 - (1) If Status LED blinks slowly, the system is running properly.
 - (2) If SIM1 or SIM2 indicator is static green, the gateway is connected to network already.


Chapter 3 Access to Web GUI

This chapter explains how to access to Web GUI of the UG87-LW.


3.1 PC Configuration for Web GUI Access to gateway

Please connect PC to GE port of UG87-LW directly. PC can obtain an IP address, or you can configure a static IP address manually. The following steps are based on Windows 10 operating system for your reference.


The following steps are based on Windows 10 operating system for your reference.




① Click "Search Box" to search "Control Panel" on the Windows 10 taskbar.




② Click "Control Panel" to open it, and then click "View network status and tasks".




③ Click "Ethernet" (May have different name).




④ Click "Properties".



⑤ Double Click "Internet Protocol Version 4 (TCP/IPv4)" to configure IP address and DNS server.



⑥ Method 1: click "Obtain an IP address automatically";



Method 2: click "Use the following IP address" to assign a static IP manually within the same subnet of the gateway.

(Note: remember to click "OK" to finish configuration.)

3.2 Access to Web GUI of gateway

Ursalink gateway provides Web-based configuration interface for management. If this is the first time you configure the gateway, please use the default settings below.

Username: admin

Password: password

IP Address: 192.168.1.1

DHCP Server: Enabled


1. Start a Web browser on your PC (Chrome and IE are recommended), type in the IP address, and press Enter on your keyboard.
2. Enter the username, password, and click "Login".



If the SIM card is connected to cellular network with public IP address, you can access WEB GUI remotely via the public IP address when remote access is enabled.


! If you enter the username or password incorrectly more than 5 times, the login page will be locked for 10 minutes.

- When you login with the default username and password, you will be asked to modify the password. It's suggested that you change the password for the sake of security. Click "Cancel" button if you want to modify it later.



The image shows a 'Change Password' dialog box with three input fields: 'Old Password', 'New Password', and 'Confirm New Password'. Below the fields are two buttons: 'Save' and 'Cancel'.

- After you login the Web GUI, you can view system information and perform configuration on the gateway.



The image shows the URSA LINK Web GUI interface. The left sidebar contains a navigation menu with the following items: Status, LoRa/WAN, Network, System, Industrial, Maintenance, and APP. The main content area is titled 'System Information' and displays the following data:


Parameter	Value
Model	UG87-LW
Partnumber	L00E-S1122-GPS
Serial Number	621683271973
Firmware Version	87.1.0.2
Hardware Version	V1.3
Local Time	2018-09-04 17:04:49
Uptime	02:42:41
CPU Load	10%
RAM (Capacity/Available)	512MB/275MB(53.71%)
Flash (Capacity/Available)	64MB/37MB(57.81%)
eMMC (Capacity/Available)	3.6G/3.1G(84%)

Chapter 4 Web Configuration

4.1 Status

4.1.1 Overview

You can view the system information of the gateway on this page.



Status	Overview	LoRa	Cellular	Network
LoRaWAN	System Information			
Network	Model		UG87-LW	
System	Partnumber		L00E-S1122-GPS	
Industrial	Serial Number		621683271873	
Maintenance	Firmware Version		87.1.0.2	
APP	Hardware Version		V1.3	
	Local Time		2018-09-04 17:04:49	
	Uptime		02:42:41	
	CPU Load		10%	
	RAM (Capacity/Available)		512MB/275MB(53.71%)	
	Flash (Capacity/Available)		64MB/37MB(57.81%)	
	eMMC (Capacity/Available)		3.6G/3.1G(94%)	

Figure 4-1-1-1

System Information	
Item	Description
Model	Show the model name of gateway.
Serial Number	Show the serial number of gateway.
Firmware Version	Show the currently firmware version of gateway.
Hardware Version	Show the currently hardware version of gateway.
Local Time	Show the currently local time of system.
Uptime	Show the information on how long the gateway has been running.
CPU Load	Show the current CPU utilization of the gateway.
RAM (Capacity/Available)	Show the RAM capacity and the available RAM memory.
Flash (Capacity/Available)	Show the Flash capacity and the available Flash memory.
eMMC (Capacity/Available)	Show the eMMC capacity and the available eMMC memory.

Table 4-1-1-1 System Information

4.1.2 LoRa WAN

You can view the LoRaWAN status of gateway on this page.

Basic	
Mode	Packet Forwarder
Version	4.0.1
Status	Running
Gateway ID	24E124FFFEF0132D
Region Code	AS923
Server Address	localhost
Uplink	
Packet Received	1
Packets Received State	CRC_OK: 0.00%, CRC_FAIL: 100.00%, NO_CRC: 0.00%
Packet Forwarded	1 (208 bytes)
Push Data Datagrams Sent	1 (456 bytes)
Push Data Acknowledged	0.00%
Downlink	
Pull Data Sent	3 (0.00% acknowledged)
Pull Resp Datagrams Received	0 (0 bytes)
Packets Sent to node	0 (0 bytes)
Packets Sent Errors	0

Figure 4-1-4-4

LoRaWAN Status (Packet Forwarder Mode)	
Item	Description
Mode	Show the working mode of LoRaWAN.
Version	Show the version of packet forwarder software.
Status	Show the status of packet forwarder. Value include Running, Disabled.
Gateway ID	Show the ID of the gateway.
Region Code	Show the LoRa region code which is based on the gateway's variant..
Server Address	Show the IP address of remote LoRaWAN network server.
Packet Received	Show the count of data packet from node to gateway.
Packets received State	Show the RF packets receiving state: CRC_OK: Percentage of CRC verification CRC_Fail: Percentage of CRC verification failure NO_CRC: Percentage of abnormal packets without CRC
Packets forwarded	Packets that CRC verified are sent from gateway to server.
Push Data Datagrams Sent	The total quantity of packets sent from gateway to server, including the RF packets forwarded and statistics packets.

Push Data Acknowledged	Percentage of acknowledged packets among Push Data Datagrams Sent.
Pull Data Sent	Show the number of keepalive packets sent to the server, and percentage of acknowledged packet regarding the keepalive packet from the server.
Pull Resp Datagrams Received	Show the packet counts and size that will be sent from server to gateway.
RF Packets Sent to node	Show the RF packet counts and size that will be sent from gateway to node.
RF Packets Sent Errors	Show the RF packet counts that fail to be sent from server to node.


Table 4-1-4-4 LoRaWAN Status (Packet Forwarder Mode)





Figure 4-1-4-5

LoRaWAN Status (Network Server)	
Item	Description
Mode	Show the working mode of LoRaWAN.
Version	Show the version of installed lora network server file.
Status	Show the status of network server. Value include Running, Disabled.
EUI	Show the identifier of the gateway.
Ch0	Show the number of packets received on Ch0.
Ch1	Show the number of packets received on Ch1.
Ch2	Show the number of packets received on Ch2.
Ch3	Show the number of packets received on Ch3.
Ch4	Show the number of packets received on Ch4.
Ch5	Show the number of packets received on Ch5.
Ch6	Show the number of packets received on Ch6.
Ch7	Show the number of packets received on Ch7.
LoRa	Show the number of packets received on LoRa.
FSK	Show the number of packets received on FSK.

Table 4-1-4-5 LoRa WAN-Status-Network Server

Click  to clean every channel's data, then the packet receive counter will be restarted.

Click  to view the details of the connected gateway, as the following picture shows.



Gateway Details											
Gateway EUI	24E124FFFE0B7443										
IP Address	localhost										
Version	4.0.1										
Uplink	1170										
Downlink	15										
Ch0	Ch1	Ch2	Ch3	Ch4	Ch5	Ch6	Ch7	LoRa	FSK	CRC	Total
923.0	923.2	923.4	922.0	922.2	922.4	922.6	922.8	922.1	922.6		
0	29	10	0	0	0	1146	0	0	1146	3	1188

Figure 4-1-4-6

LoRa WAN-Network Server-Status-Gateway Detail	
Item	Description
Gateway EUI	Show the identifier of the gateway.
IP Address	Show the IP address of the gateway.
Version	Show the version of packet forwarder software.
Uplink	Show the number of uplink packets which the gateway received.
Downlink	Show the number of downlink packets which the gateway received.
Ch0	Show the frequency of Ch0 and number of packets received on Ch0.
Ch1	Show the frequency of Ch1 and number of packets received on Ch1.
Ch2	Show the frequency of Ch2 and number of packets received on Ch2.
Ch3	Show the frequency of Ch3 and number of packets received on Ch3.
Ch4	Show the frequency of Ch4 and number of packets received on Ch4.
Ch5	Show the frequency of Ch5 and number of packets received on Ch5.
Ch6	Show the frequency of Ch6 and number of packets received on Ch6.
Ch7	Show the frequency of Ch7 and number of packets received on Ch7.
LoRa	Show the frequency of LoRa channel and number of packets received on LoRa channel.
FSK	Show the frequency of FSK channel and number of packets received on FSK channel.
CRC	Show the total number of packets with CRC error.
Toal	Show the total number of packets received by the gateway.

Table 4-1-4-6 LoRa WAN-Network Server-Status-Gateway Detail

4.1.3 Cellular

You can view the cellular network status of gateway on this page.

Overview	Cellular	Network	VPN	Routing	Host List
Modem					
Status	Ready				
Model	EC25				
Current SIM	SIM1				
Signal Level	15asu (-83dBm)				
Register Status	Registered (Home network)				
IMSI	460019987103071				
ICCID	89860117838019196629				
ISP	CHN-UNICOM				
Network Type	LTE				
PLMN ID	46001				
LAC	5922				
Cell ID	812c63d				
IMEI	861107031710008				

Figure 4-1-2-1

Modem Information	
Item	Description
Status	Show corresponding detection status of module and SIM card.
Model	Show the model name of cellular module.
Current SIM	Show the current SIM card used.
Signal Level	Show the cellular signal level.
Register Status	Show the registration status of SIM card.
IMSI	Show IMSI of the SIM card.
ICCID	Show ICCID of the SIM card.
ISP	Show the network provider which the SIM card registers on.
Network Type	Show the connected network type, such as LTE, 3G, etc.
PLMN ID	Show the current PLMN ID, including MCC, MNC, LAC and Cell ID.
LAC	Show the location area code of the SIM card.
Cell ID	Show the Cell ID of the SIM card location.
IMEI	Show the IMEI of the module.

Table 4-1-2-1 Modem Information

Network	
Status	Connected
IP Address	10.53.241.18
Netmask	255.255.255.252
Gateway	10.53.241.17
DNS	218.104.128.106
Connection Duration	0 days, 00:04:26

Figure 4-1-2-2

Network Status	
Item	Description
Status	Show the connection status of cellular network.
IP Address	Show the IP address of cellular network.
Netmask	Show the netmask of cellular network.
Gateway	Show the gateway of cellular network.
DNS	Show the DNS of cellular network.
Connection Duration	Show information on how long the cellular network has been connected.

Table 4-1-2-2 Network Status

4.1.4 Network

On this page you can check the LAN status of the gateway.

WAN							
Port	Status	Type	IP Address	Netmask	Gateway	DNS	Duration
GE 0	up	Static	192.168.23.94	255.255.255.0	192.168.23.1	114.114.114.114	12m 14s

Figure 4-1-3-1

LAN Status	
Item	Description
Port	Show the name of WAN port.
Status	Show the status of WAN port. "Up" refers to a status that WAN is enabled and Ethernet cable is connected. "Down" means Ethernet cable is disconnected or WAN function is disabled.
Type	Show the dial-up type of WAN port.
IP Address	Show the IPv address of WAN port.
Netmask	Show the netmask of WAN port.
Gateway	Show the gateway of WAN port.
DNS	Show the DNS of WAN port.

Duration	Show the information about how long the Ethernet cable has been connected to WAN port when WAN function is enabled. Once WAN function is disabled or Ethernet cable is disconnected, the duration will stop.
----------	--

Table 4-1-3-1 LAN Status

4.1.5 VPN

You can check VPN status on this page, including PPTP, L2TP, IPsec, OpenVPN and DMVPN.

Overview	Cellular	Network	<u>VPN</u>	Routing	Host List
PPTP Tunnel					
Name	Status	Local IP	Remote IP		
pptp_1	Disconnected	-	-		
pptp_2	Disconnected	-	-		
pptp_3	Disconnected	-	-		
L2TP Tunnel					
Name	Status	Local IP	Remote IP		
l2tp_1	Disconnected	-	-		
l2tp_2	Disconnected	-	-		
l2tp_3	Disconnected	-	-		

Figure 4-1-4-1

Overview	Cellular	Network	<u>VPN</u>	Routing	Host List
IPsec Tunnel					
Name	Status	Local IP	Remote IP		
ipsec_1	Disconnected	-	-		
ipsec_2	Disconnected	-	-		
ipsec_3	Disconnected	-	-		
OpenVPN Client					
Name	Status	Local IP	Remote IP		
openvpn_1	Disconnected	-	-		
openvpn_2	Disconnected	-	-		
openvpn_3	Disconnected	-	-		

Figure 4-1-4-2

GRE Tunnel				
Name	Status	Local IP	Remote IP	
gre_1	Disconnected	-	-	
gre_2	Disconnected	-	-	
gre_3	Disconnected	-	-	

DMVPN Tunnel				
Name	Status	Local IP	Remote IP	
dmpvn	Disconnected	-	-	

Figure 4-1-4-3

VPN Status	
Item	Description
Name	Show the name of the VPN tunnel.
Status	Show the status of the VPN tunnel.
Local IP	Show the local tunnel IP of VPN tunnel.
Remote IP	Show the remote tunnel IP of VPN tunnel.

Table 4-1-4-1 VPN Status

4.1.6 Routing Information

You can check routing status on this page, including the routing table and ARP cache.

Overview	Cellular	Network	VPN	Routing	Host List
Routing Table					
Destination	Netmask	Gateway	Interface	Metric	
0.0.0.0	0.0.0.0	192.168.23.1	GE	1	
127.0.0.0	255.0.0.0	-	Loopback	-	
192.168.23.0	255.255.255.0	-	GE	-	

ARP Cache		
IP	MAC	Interface
192.168.23.21	e0:d5:5e:50:b4:c0	GE
192.168.23.111	00:00:00:00:00:00	GE
192.168.23.40	1c:1b:0d:f8:fe:06	GE
192.168.23.1	24:e1:24:f0:01:97	GE

Figure 4-1-6-1

Item	Description
Routing Table	

Destination	Show the IP address of destination host or destination network.
Netmask	Show the netmask of destination host or destination network.
Gateway	Show the IP address of the gateway.
Interface	Show the outbound interface of the route.
Metric	Show the metric of the route.
ARP Cache	
IP	Show the IP address of ARP pool.
MAC	Show the IP address's corresponding MAC address.
Interface	Show the binding interface of ARP.

Table 4-1-6-1 Routing Information

4.1.7 Host List

You can view the host information on this page.



Figure 4-1-7-1

Host List	
Item	Description
DHCP Leases	
IP Address	Show IP address of DHCP client
MAC Address	Show MAC address of DHCP client
Lease Time Remaining	Show the remaining lease time of DHCP client.
MAC Binding	
IP & MAC	Show the IP address and MAC address set in the Static IP list of DHCP service.

Table 4-1-7-1 Host List Description

4.2 LoRa




Figure 4-2-1-1

4.2.1 Packet Forwarder

4.2.1.1 General

Status	General	Radios	Advanced	Custom	Traffic
LoRaWAN	General Setting Enable <input checked="" type="checkbox"/> Please close the Network Server mode first. Mode: Packet Forwarder Gateway EUI: 24E124FFFE0B6543 Gateway ID: 24E124FFFE0B6543 Server Address: localhost Server Up Port: 1700 Server Down Port: 1700				
Packet Forwarder					
Network Server					
Network					
System					
Industrial					
Maintenance					
APP					

Figure 4-2-1-2

General Setting		
Item	Description	Default
Enable	Click to enable the Packet Forwarder mode.	Enabled
Gateway EUI	Show the identifier of the gateway.	Generated from MAC address of the gateway and cannot be changed.
Gateway ID	Fill in the corresponding ID which you've used for	The default is the

	register gateway on the remote network server, such as TTN. It is usually the same with gateway EUI and can be changed.	same with gateway EUI.
Server Address	Enter the IP address of the LoRaWAN network server.	Null
Server Up Port	Enter the port of the LoRaWAN network server to upload data. Range: 1-65535.	1700
Server Down Port	Enter the port of the LoRaWAN network server to send data to your gateway. Range: 1-65535.	1700

Table 4-2-1-1 General Setting Parameters

4.2.1.2 Radios




Figure 4-2-1-3

Radios-Radio Channels Setting		
Item	Description	Default
Supported Frequency	Choose the LoRaWAN frequency plan used for the upstream and downlink frequencies and datarates. Available channel plans depend on the gateway's variant.	The default frequency is set based on the gateway's variant.
Name	Show the name of central frequency.	
Center Frequency	Enter the central frequency of Radio 0 which supports transmitting and receiving packet. Enter the center frequency of Radio 1 which only supports receiving packet from nodes.	Null

Table 4-2-1-2 Radio Channels Setting Parameters

Multi Channels Setting

Enable	Index	Radio	Frequency/MHz
<input checked="" type="checkbox"/>	0	Radio 0	923.2
<input checked="" type="checkbox"/>	1	Radio 0	923.4
<input checked="" type="checkbox"/>	2	Radio 0	923.6
<input checked="" type="checkbox"/>	3	Radio 1	922.2
<input checked="" type="checkbox"/>	4	Radio 1	922.4
<input checked="" type="checkbox"/>	5	Radio 1	922.6
<input checked="" type="checkbox"/>	6	Radio 1	922.8
<input checked="" type="checkbox"/>	7	Radio 1	923.0

Figure 4-2-1-4

Radios-Multi Channel Setting		
Item	Description	Default
Enable	Click to enable this channel to transmit packets.	Enabled
Index	Indicate the ordinal of the list.	
Radio	Choose Radio 0 or Radio 1 as center frequency.	Radio 0
Frequency/MHz	Enter the frequency of this channel. Range: center frequency ± 0.9 .	The default frequency is set based on the supported frequency you have selected.

Table 4-2-1-3 Multi Channel Setting Parameters

LoRa Channel Setting

Enable	Radio	Frequency/MHz	Bandwidth/KHz	Spread Factor
<input checked="" type="checkbox"/>	Radio 0	923.8	250KHZ	SF7

Figure 4-2-1-5

Radios-LoRa Channel Setting		
Item	Description	Default
Enable	Click to enable this channel to transmit packets.	Enabled
Radio	Choose Radio 0 or Radio 1 as center frequency.	Radio 0
Frequency/MHz	Enter the frequency of this channel. Range: center frequency ± 0.9 .	The default frequency is set based on the supported frequency you have selected.
Bandwidth/MHz	Enter the bandwidth of this channel. Recommended value: 125KHz, 250KHz, 500KHz	125KHz
Spread Factor	Choose the selectable spreading factor. The channel with large spreading Factor corresponds to a low rate, while the small one corresponds to a high rate.	The default is based on what is specified in the LoRaWAN regional parameters document.

Table 4-2-1-4 LoRa Channel Setting Parameters

The screenshot shows the 'FSK Channel Setting' interface. It contains five main fields: 'Enable' (checked), 'Radio' (set to 'Radio 0'), 'Frequency/MHz' (set to '924.0'), 'Bandwidth/KHz' (set to '125KHZ'), and 'DataRate' (set to '50000').

Figure 4-2-1-6

Radios-FSK Channel Setting		
Item	Description	Default
Enable	Click to enable this channel to transmit packets.	Disabled
Radio	Choose Radio 0 or Radio 1 as center frequency.	Radio 0
Frequency/MHz	Enter the frequency of this channel. Range: center frequency \pm 0.9.	The default frequency is set based on the supported frequency you have selected.
Bandwidth/MHz	Enter the bandwidth of this channel. Recommended value: 125KHz, 250KHz, 500KHz	500KHz
Data Rate	Enter the data rate. Range: 500-25000.	500

Table 4-2-1-5 FSK Channel Setting Parameters

4.2.1.3 Advanced

The screenshot shows the 'Advanced' settings page for Radios. It is divided into three sections:

- Intervals Setting:** Includes 'Keep Alive Interval' (10 s), 'Stat Interval' (30 s), and 'Push Timeout' (100 ms).
- Forward CRC Setting:** Includes 'Forward CRC Disabled' (unchecked), 'Forward CRC Error' (checked), and 'Forward CRC Valid' (checked).
- Network Setting:** Includes 'Network Mode' (set to 'Private LoRaWAN').

 A 'Save' button is located at the bottom left of the settings area.

Figure 4-2-1-7

Advanced		
Item	Description	Default
Keep Alive Interval	Enter the interval of keepalive packet which is sent from gateway to LoRaWAN network server to keep the connection stable and alive. Range: 1-3600.	10
Stat Interval	Enter the interval to update the network server with gateway statistics. Range: 1-3600.	30
Push Timeout	Enter the timeout to wait for the response from server after the gateway sends data of node. Rang: 1-3600.	100
Forward CRC Disabled	Enable to send packets received with CRC disabled to the network server.	Disabled.
Forward CRC Error	Enable to send packets received with CRC errors to the network server.	Disabled.
Forward CRC Valid	Enable to send packets received with CRC valid to the network server.	Enabled
Network Mode	select from "Public LoRaWAN", "Private LoRaWAN". Public LoRaWAN: telecom/operator managed networks, connect multiple applications (multi-tenant) into a single network. Private LoRaWAN: individually managed networks, Network deployed for single application purpose.	Public LoRaWAN

Table 4-2-1-6 Advanced Parameters

4.2.1.4 Custom

The screenshot displays the 'Custom Configuration' tab in a web interface. At the top, there are navigation tabs: 'General', 'Radios', 'Advanced', 'Custom' (selected), and 'Traffic'. Below the tabs, the 'Custom Configuration' section is visible. It features an 'Enable' checkbox which is checked. To the right of the checkbox is a link labeled 'Example'. Below the checkbox is a large text area containing a JSON configuration file example. The JSON content is as follows:

```
{
  "SX1301_conf": {
    "lorawan_public": true,
    "clksrc": 1, /* radio_1 provides clock to concentrator */
    "antenna_gain": 0, /* antenna gain, in dBi */
    "radio_0": {
      "enable": true,
      "type": "SX1257",
      "freq": 922500000,
      "rssi_offset": -162,
      "tx_enable": true,
      "tx_freq_min": 917000000,
      "tx_freq_max": 923500000
    },
    "radio_1": {
      "enable": true,
      "type": "SX1257"
    }
  }
}
```

At the bottom of the configuration area, there are two buttons: 'Save & Apply' and 'Clear'.

Figure 4-2-1-8

When Custom Configuration mode is enabled, you can write your own packet forwarder configuration file in the edit box to configure packet forwarder. Click “Save” to save your custom configuration file content, and click “Apply” to take effect. You can click “Clear” to erase all content in the edit box. If you don’t know how to write configuration file, please click “Example” to go to reference page.

4.2.1.5 Traffic

When navigating to the traffic page, any recent traffic received by the gateway will display. To watch live traffic, click Start.

Traffic Setting								
Refresh		Clear						
Rfch	Direction	Time	Ticks	Frequency	Datarate	Coderate	RSSI	SNR
1	up	-	83002508	922.8	SF9BW125	4/5	-103	-13.2
1	up	-	71108156	922.6	SF9BW125	4/5	-102	-13.2
1	up	-	35426956	922.8	SF9BW125	4/5	-103	-9.8
1	up	-	3171639508	922.6	SF9BW125	4/5	-100	-10.5
1	up	-	3199744804	922.6	SF9BW125	4/5	-102	-13.8
1	up	-	3195781348	922.6	SF9BW125	4/5	-101	-12.2
1	up	-	3147851688	922.6	SF9BW125	4/5	-102	-13.8
1	up	-	3143888916	922.8	SF9BW125	4/5	-102	-13.2
1	up	-	3199922748	922.8	SF9BW125	4/5	-100	-12.2
1	up	-	3124065788	922.8	SF9BW125	4/5	-100	-12.8

Figure 4-2-1-9

Item	Description
Refresh	Click to obtain the latest data.
Clear	Click to clear all data.
Rfch	Show the channel of this packet.
Direction	Show the direction of this packet.
Time	Show the receiving time of this packet.
Ticks	Show the ticks of this packet.
Frequency	Show the frequency of the channel.
Datarate	Show the datarate of the channel.
Coderate	Show the coderate of this packet.
RSSI	Show the received signal strength.
SNR	Show the signal to noise ratio of this packet.

Table 4-2-1-7 Traffic Parameters

4.2.2 Network Server

4.2.2.1 General




Figure 4-2-2-1

Item	Description	Default
General Setting		
Enable	Click to enable Network Server mode.	Disabled
NetID	Enter the network identifier.	01023
Join Delay	Enter the interval time between the end-device sends a Join_request_message to network server and the end-device prepares to open RX1 to receive the Join_accept_message sent from network server.	5
RX1 Delay	Enter the interval time between the end-device sends uplink packets and the end-device prepares to open RX1 to receive the downlink packet.	1
Lease Time	Enter the amount of time until a successful join expires. The format is hours-minutes-seconds. If the join-type is OTAA, then the end-devices need to join the network server again when it exceeds the lease time.	"744-00-00"
Loglevel	Choose the log level.	Info
Channel Plan Setting		
Channel Plan	Choose LoRaWAN channel plan used for the upstream and downlink frequencies and	Depend on the gateway's variant.

	<p>datarates. Available channel plans depend on the gateway's variant.</p>	
Channel Mask	<p>Enabled frequencies are controlled using channel mask.</p> <p>Leave it blank means using the default standard usable channels which are specified in the LoRaWAN regional parameters document.</p> <p>A bit in the ChMask field set to 1 means that the corresponding channel can be used for uplink transmissions if this channel allows the data rate currently used by the end-device.</p> <p>A bit set to 0 means the corresponding channels should be avoided.</p> <p>US and AU 915 have a 80-bit channel mask for 72 usable channels and EU, AS, IN, KR have a 16-bit mask for 16 usable channels.</p>	<p>Null.</p> <p>Null means using the default standard usable channels which are specified in the LoRaWAN regional parameters document.</p>

Table 4-2-2-1 General Parameters

Note: For some regional variants, If allowed by your LoRaWAN region, you can use Additional Plan to configure additional channels that are not defined by the LoRaWAN Regional Parameters, like EU868 and KR920, as the following picture shows:



Figure 4-2-2-2

Additional Channels		
Item	Description	Default
Frequency/MHz	Enter the frequency of the additional plan.	Null.
Max Datarate	Enter the max datarate for the end-device. The range is based on what is specified in the LoRaWAN regional parameters document.	DR0(SF12,125kHz)
Min Datarate	Enter the min datarate for the end-device. The range is based on what is specified in the LoRaWAN regional parameters document.	DR3(SF9,125kHz)

Table 4-2-2-2 Additional Plan Parameters

4.2.2.2 Application

Devices can communicate with applications that they've been registered. To register a device, you'll first need to create an application (define the method you want to decode the data sent from end-device) and a device profile (define the join-type and LoRaWAN classes). You don't have to create new application profile and device profile when you add a new device which its "Payload Codec", "Join Type", "Class Type" are the same with existing device. You can just choose the corresponding profiles.

You can see the information about the application you have created in this page.

ID	Name	Description	Payload Codec	Operation
1	Ursalink-app	a application for ursalink test	None	
2	AS923	s	Cayenne LPP	

Figure 4-2-2-3

Item	Description
ID	Show the ID of the application profile already created.
Name	Show the name of the application profile already created.
Description	Show the description of the application profile already created.
Payload Codec	Show the payload codec of the application profile already created.

Table 4-2-2-3 Application Parameters

You can edit the application by clicking or create a new application by clicking .

Related Configuration Example

[Application configuration](#)

4.2.2.3 Profiles

You can view the information about the device profiles which you have created in this page.

Name	Max TXPower	Join Type	Class Type	Operation
Device-test	0	OTAA	Class A	
Ursalink-test-ABP	0	ABP	Class A	
niiii	0	OTAA	Class A	

Figure 4-2-2-4

Item	Description
Name	Show the name of the device profile.
Max Tx power	Show the Tx power of the device profile.
Join Type	Show the join type of the device profile.
Class Type	Show the class type of the device profile.

Table 4-2-2-4 Device profiles setting Parameters

You can edit the device profile by clicking  or create a new device profile by clicking .

Related Configuration Example

[Device Profiles Advanced configuraion](#)

4.2.2.4 Device



Device Name	Device EUI	Device-Profile	Application	Last Seen	Activated	Operation
asd	3530353083376118	ninii	AS923	53 minutes ago	✓	 

Figure 4-2-2-5


Item	Description
Device Name	Show the name of the device.
Device EUI	Show the EUI of the device.
Device-Profile	Show the name of the device’s device profile.
Application	Show the name of the device’s application.
Last Seen	Show the time of last packet received.
Activated	Show the status of the device .  means that the device has been activated.

Table 4-2-2-5 Device Parameters

You can edit the device by clicking  or create a new device by clicking .

Related Configuration Example

[Device configuration](#)


4.2.2.5 Packet

Device EUI	Frequency	Datarate	SNR	RSSI	Size	Fcnt	Type	Time	Details
3530353083376118	923200000	SF10BW12 5	-	-	0	0	DnUnc	2018-09-04T09:05:49+08:00	!
3530353083376118	923200000	SF10BW12 5	10.5	-45	8	0	UpCnf	2018-09-04T09:05:48+08:00	!
3530353083376118	923400000	SF10BW12 5	-	-	17	0	JnAcc	2018-09-04T09:05:28+08:00	!
3530353083376118	923400000	SF10BW12 5	10.2	-38	18	0	JnReq	2018-09-04T09:05:28+08:00	!

Figure 4-2-2-6

Item	Description
Device EUI	Show the EUI of the device.
Frequency	Show the used frequency to transmit packets.
Datarate	Show the used datarate to transmit packets.
SNR	Show the signal-noise ratio.
RSSI	Show the received signal strength indicator.
Size	Show the size of payload.
Fcnt	Show the frame counter.
Type	Show the type of the packet: JnAcc - Join Accept Packet JnReq - Join Request Packet UpUnc - Uplink Unconfirmed Packet UpCnf - Uplink Confirmed Packet - ACK response from network requested DnUnc - Downlink Unconfirmed Packet DnCnf - Downlink Confirmed Packet- ACK response from end-device requested
Time	Show the time of packet was sent or received.

Table 4-2-2-6 Packet Parameters

Click  to get more details about the packet. As shown:




Figure 4-2-2-7

Item	Description
Dev Addr	Show the address of the device.
GwEUI	Show the EUI of the gateway.
AppEUI	Show the EUI of the application.
DevEUI	Show the EUI of the device.
Immediately	True: Device may transmit an explicit (possibly empty) acknowledgement data message immediately after the reception of a data message requiring a confirmation.
TimeSinceGPS Epoch	Show the GPS time.
Timestamp	Show the timestamp of this packet.
Frequency	Show the frequency of this channel.
Type	Show the type of the packet: JnAcc - Join Accept Packet JnReq - Join Request Packet UpUnc - Uplink Unconfirmed Packet UpCnf - Uplink Confirmed Packet - ACK response from network requested DnUnc - Downlink Unconfirmed Packet DnCnf - Downlink Confirmed Packet- ACK response from end-device requested
Adr	True: The end-node has enabled ADR. False: The end-node has not enabled ADR.
AdrAckReq	In order to validate that the network is receiving the uplink messages, nodes periodically transmit ADRAckReq message. This is 1 bit long. True:Network should respond in ADR_ACK_DELAY time to confirm that it

	is receiving the uplink messages False: Otherwise
Ack	True: This frame is ACK. False: This frame is not ACK.
Fcnt	Show the frame-counter of this packet.The network server tracks the uplink frame counter and generates the downlink counter for each end-device.
FPort	FPort is a multiplexing port field. If the frame payload field is not empty, the port field must be present. If present, a FPort 16 value of 0 indicates that the FRMPayload contains MAC commands only.When this is the case, the FOptsLen field must be zero. FOptsLen is the length of the FOpts field in bytes.
Modulation	LoRa means the physical layer uses the LoRa modulation
Bandwidth	Show the bandwidth of this channel.
SpreadFactor	Show the spreadFactor of this channel.
Bitrate	Show the bitrate of this channel.
CodeRate	Show the coderate of this channel.
SNR	Show the SNR of this channel.
RSSI	Show the RSSI of this channel.
Power	Show the transmit power of the device.
Payload (b64)	Show the application payload of this packet.
Payload (hex)	Show the application payload of this packet.
MIC	Show the MIC of this packet.MIC is a cryptographic message integrity code, computed over the fields MHDR, FHDR, FPort and the encrypted FRMPayload.

Table 4-2-2-7 Packets Details Parameters

4.3 Network

4.3.1 Interface

4.3.1.1 Port




Figure 4-3-1-1

Port Setting	
Item	Description

Port	Users can define the Ethernet ports according to their needs.
Status	Set the status of Ethernet port; select "up" to enable and "down" to disable.
Property	LAN. User cannot change this setting.
Speed	Set the Ethernet port's speed. The options are "auto", "1000 Mbps", "100 Mbps", and "10 Mbps".
Duplex	Set the Ethernet port's mode. The options are "auto", "full", and "half".

Table 4-3-1-1 Port Parameters

4.3.1.2 WAN

WAN port can be connected with Ethernet cable to get Internet access. It supports 3 connection types.

- **Static IP:** configure IP address, netmask and gateway for Ethernet WAN interface.
- **DHCP Client:** configure Ethernet WAN interface as DHCP Client to obtain IP address automatically.
- **PPPoE:** configure Ethernet WAN interface as PPPoE Client.




Figure 4-3-1-2

WAN Setting		
Item	Description	Default
Enable	Enable WAN function	Enable
Port	The port that is currently set as WAN port.	GE 0
Connection Type	Select from "Static IP", "DHCP Client" and "PPPoE".	Static IP
MTU	Set the maximum transmission unit.	1500

Primary DNS Server	Set the primary DNS.	Null
Secondary DNS Server	Set the secondary DNS.	Null
Enable NAT	Enable or disable NAT function. When enabled, a private IP can be translated to a public IP.	Enable

Table 4-3-1-2 WAN Parameters

1. Static IP Configuration

If the external network assigns a fixed IP for the WAN interface, user can select “Static IP” mode.




Figure 4-3-1-3

Static IP		
Item	Description	Default
IP Address	Set the IP address which can access Internet. E.g. 192.168.1.2.	192.168.0.1
Netmask	Set the Netmask for WAN port.	255.255.255.0
Gateway	Set the gateway's IP address for WAN port.	192.168.0.2
Multiple IP Address	Set the multiple IP addresses for WAN port.	Null

Table 4-3-1-3 Static Parameters

2. DHCP Client

If the external network has DHCP server enabled and has assigned IP addresses to the Ethernet WAN interface, user can select “DHCP client” mode to obtain IP address automatically.




Figure 4-3-1-4

DHCP Client	
Item	Description
Use Peer DNS	Obtain peer DNS automatically during PPP dialing. DNS is necessary when user visits domain name.

Table 4-3-1-4 DHCP Client Parameters

3. PPPoE

PPPoE refers to a point to point protocol over Ethernet. User has to install a PPPoE client on the basis of original connection way. With PPPoE, remote access devices can get control of each user.




Figure 4-3-1-5

PPPoE	
Item	Description
Username	Enter the username provided by your Internet Service Provider (ISP).
Password	Enter the password provided by your Internet Service Provider (ISP).
Link Detection Interval (s)	Set the heartbeat interval for link detection. Range: 1-600.
Max Retries	Set the maximum retry times after it fails to dial up. Range: 0-9.
Use Peer DNS	Obtain peer DNS automatically during PPP dialing. DNS is necessary when user visits domain name.

Table 4-3-1-5 PPOE Parameters

4.3.1.3 LAN

LAN setting is used for managing local area network devices connected to LAN port of the UG87-LW, allowing each device to access the Internet.

Click  to delete the existing LAN port setting. Click  to add a new LAN port setting.




Figure 4-3-1-6

LAN		
Item	Description	Default
Port	Select LAN port.	GE
IP Address	Set IP address of LAN port.	192.168.1.1
Netmask	Set Netmask of LAN port.	255.255.255.0
MTU	Set the maximum transmission unit of LAN port. Range: 68-1500.	1500

Table 4-3-1-6

4.3.1.4 VLAN Trunk

VLAN is a kind of new data exchange technology that realizes virtual work groups by logically dividing the LAN device into network segments.

Client  to delete the current VLAN setting. Click  to add a new VLAN port.




Figure 4-3-1-7

VLAN Trunk	
Item	Description
Enable	The gateway can encapsulate or decapsulate the virtual LAN tag when this function is enabled.
Interface	Select the VLAN interface from the LAN ports.
VID	Set the label ID of the VLAN. Range: 1-4094.
IP Address	Set VLAN port's IP address.
Netmask	Set VLAN port's netmask.

Table 4-3-1-7 VLAN Trunk Parameters

4.3.1.5 Cellular

This section explains how to set the related parameters for cellular network. The UG87-LW LoRaWAN gateway has two cellular interfaces, namely SIM1 and SIM2. Only one cellular interface is active at one time. If both cellular interfaces are enabled, then SIM1 interface takes precedence by default.

A typical use case would be to have SIM1 configured as the primary cellular interface and SIM2 as a backup. If the UG87-LW cannot connect to the network via SIM1, it will automatically fail over to SIM2.

Port	WAN	LAN	VLAN Trunk	Cellular	Loopback
Cellular Setting					
				SIM1	SIM2
Enable				<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>
Network Type				<input type="text"/>	<input type="text"/>
APN				<input type="text"/>	<input type="text"/>
Username				<input type="text"/>	<input type="text"/>
Password				<input type="text"/>	<input type="text"/>
Access Number				<input type="text"/>	<input type="text"/>
PIN Code				<input type="text"/>	<input type="text"/>
Authentication Type				Auto	Auto
Roaming				<input type="checkbox"/>	<input type="checkbox"/>
SMS Center				<input type="text"/>	<input type="text"/>

Figure 4-3-1-8

Connection Setting	<input type="checkbox"/>
Dual SIM Strategy	<input type="checkbox"/>
Enable NAT	<input checked="" type="checkbox"/>
Restart When Dial-up failed	<input type="checkbox"/>
ICMP Server	<input type="text" value="8.8.8.8"/>
Secondary ICMP Server	<input type="text" value="114.114.114.114"/>
PING Times	<input type="text" value="5"/>
Packet Loss Rate	<input type="text" value="20"/> %
SMS Settings	
SMS Mode	<input type="text" value="PDU"/>

Figure 4-3-1-9

General Settings		
Item	Description	Default
Enable	Check the option to enable the corresponding SIM card.	Enable
Network Type	Select from "Auto", "4G First", "4G Only", "3G First", "3G Only", "2G Frist", and "2G Only". Auto: connect to the network with the strongest signal automatically. 4G First: 4G network takes precedence. 4G Only: connect to 4G network only. And so on.	Auto
APN	Enter the Access Point Name for cellular dial-up connection provided by local ISP.	Null
Username	Enter the username for cellular dial-up connection provided by local ISP.	Null
Password	Enter the password for cellular dial-up connection provided by local ISP.	Null
Access Number	Enter the dial-up center NO. For cellular dial-up connection provided by local ISP.	Null
PIN Code	Enter a 4-8 characters PIN code to unlock the SIM.	Null
Authentication Type	Select from "Auto", "PAP", "CHAP", "MS-CHAP", and "MS-CHAPv2".	Auto
Roaming	Enable or disable roaming.	Disable
SMS Center	Enter the local SMS center number for storing, forwarding, converting and delivering SMS message.	Null
Enable NAT	Enable or disable NAT function.	Enable
Restart When Dial-up failed	When this function is enabled, the gateway will restart automatically if the dial-up fails several times.	Disabled
ICMP Server	Set the ICMP detection server's IP address.	8.8.8.8
Secondary ICMP Server	Set the secondary ICMP detection server's IP address.	114.114.114.114
PING Times	Set PING packet numbers in each ICMP detection.	5
Packet Loss Rate	Set packet loss rate in each ICMP detection. ICMP detection fails when the preset packet loss rate is exceeded.	20

Table 4-3-1-8 Cellular Parameters

Connection Setting	<input checked="" type="checkbox"/>
Connection Mode	Connect on Demand ▼
Redial Interval(s)	5
Max Idle Time(s)	60
Triggered by Call	<input type="checkbox"/>
Triggered by SMS	<input type="checkbox"/>
Triggered by IO	<input type="checkbox"/>
Dual SIM Strategy	<input checked="" type="checkbox"/>
Primary SIM Card	SIM1 ▼
Switch to backup SIM card when ICMP detection fails	<input checked="" type="checkbox"/>
Switch to backup SIM card when the connection fails	<input checked="" type="checkbox"/>
Switch to backup SIM card when roaming is detected	<input type="checkbox"/>

Figure 4-3-1-10

Item	Description
Connection Mode	
Connection Mode	Select from "Always Online" and "Connect on Demand".
Connect on Demand	"Connect on Demand" includes "Triggered by Call", "Triggered by SMS", and "Triggered by IO".
Triggered by Call	The gateway will switch from offline mode to cellular network mode automatically when it receives a call from the specific phone number.
Call Group	Select a call group for call trigger. Go to "System > General > Phone" to set up phone group.
Triggered by SMS	The gateway will switch from offline mode to cellular network mode automatically when it receives a specific SMS from the specific mobile phone.
SMS Group	Select a SMS group for trigger. Go to "System > General > Phone" to set up SMS group.
SMS Text	Fill in the SMS content for triggering.
Triggered by IO	The gateway will switch from offline mode to cellular network mode automatically when the DI status is changed. Go to "Industrial > I/O > DI" to configure trigger condition.
Dual SIM Strategy	
Current SIM Card	Select between "SIM1" and "SIM2" as a current SIM card used.
Switch to backup SIM card when ICMP detection fails	The gateway will switch to the backup SIM card when packet loss rate in ICMP detection exceeds the preset value.
Switch to backup	The gateway will switch to the backup SIM card when the primary

SIM card when the connection fails	one fails to connect with cellular network.
Switch to backup SIM card when roaming is detected	The gateway will switch to the backup SIM card when the primary one is roaming.

Table 4-3-1-9 Cellular Parameters

Related Topics

[Cellular Connection Application Example](#)

[Dual SIM Backup Application Example](#)

[Phone Group](#)

4.3.1.6 Loopback

Loopback interface is used for replacing gateway's ID as long as it is activated. When the interface is DOWN, the ID of the gateway has to be selected again which leads to long convergence time of OSPF. Therefore, Loopback interface is generally recommended as the ID of the gateway.

Loopback interface is a logic and virtual interface on gateway. Under default conditions, there's no loopback interface on gateway, but it can be created as required.

Figure 4-3-1-11

Loopback		
Item	Description	Default
IP Address	Unalterable	127.0.0.1
Netmask	Unalterable	255.0.0.0
Multiple IP Addresses	Apart from the IP above, user can configure other IP addresses.	Null

Table 4-3-1-10 Loopback Parameters

4.3.2 Firewall

This section describes how to set the firewall parameters, including ACL, DMZ, Port Mapping and MAC Binding.

The firewall implements corresponding control of data flow at entry direction (from Internet to local area network) and exit direction (from local area network to Internet) according to the content features of packets, such as protocol style, source/destination IP address, etc. It ensures that the gateway operate in a safe environment and host in local area network.

4.3.2.1 ACL

Access control list, also called ACL, implements permission or prohibition of access for specified network traffic (such as the source IP address) by configuring a series of matching rules so as to filter the network interface traffic. When gateway receives packet, the field will be analyzed according to the ACL rule applied to the current interface. After the special packet is identified, the permission or prohibition of corresponding packet will be implemented according to preset strategy.

The data package matching rules defined by ACL can also be used by other functions requiring flow distinction.




Figure 4-3-2-1

Item	Description
ACL Setting	
Default Filter Policy	Select from "Accept" and "Deny". The packets which are not included in the access control list will be processed by the default filter policy.
Access Control List	
Type	Select type from "Extended" and "Standard".
ID	User-defined ACL number. Range: 1-199.

Action	Select from "Permit" and "Deny".
Protocol	Select protocol from "ip", "icmp", "tcp", "udp", and "1-255".
Source IP	Source network address (leaving it blank means all).
Source Wildcard Mask	Wildcard mask of the source network address.
Destination IP	Destination network address (0.0.0.0 means all).
Destination Wildcard Mask	Wildcard mask of destination address.
Description	Fill in a description for the groups with the same ID.
ICMP Type	Enter the type of ICMP packet. Range: 0-255.
ICMP Code	Enter the code of ICMP packet. Range: 0-255.
Source Port Type	Select source port type, such as specified port, port range, etc.
Source Port	Set source port number. Range: 1-65535.
Start Source Port	Set start source port number. Range: 1-65535.
End Source Port	Set end source port number. Range: 1-65535.
Destination Port Type	Select destination port type, such as specified port, port range, etc.
Destination Port	Set destination port number. Range: 1-65535.
Start Destination Port	Set start destination port number. Range: 1-65535.
End Destination Port	Set end destination port number. Range: 1-65535.
More Details	Show information of the port.
Interface List	
Interface	Select network interface for access control.
In ACL	Select a rule for incoming traffic from ACL ID.
Out ACL	Select a rule for outgoing traffic from ACL ID.

Table 4-3-2-1 ACL Parameters

Related Configuration Example

[Access Control Application Example](#)

4.3.2.2 DMZ

DMZ is a host within the internal network that has all ports exposed, except those forwarded ports in port mapping.

Figure 4-3-2-2


DMZ	
Item	Description
Enable	Enable or disable DMZ.
DMZ Host	Enter the IP address of the DMZ host on the internal network.
Source Address	Set the source IP address which can access to DMZ host. "0.0.0.0/0" means any address.

Table 4-3-2-2 DMZ Parameters

4.3.2.3 Port Mapping

Port mapping is an application of network address translation (NAT) that redirects a communication request from the combination of an address and port number to another while the packets are traversing a network gateway such as a gateway or firewall.

Click  to add a new port mapping rules.



Source IP	Source Port	Destination IP	Destination Port	Protocol	Description	Operation
0.0.0.0/0				TCP		X
						+

Figure 4-3-2-3

Port Mapping	
Item	Description
Source IP	Specify the host or network which can access local IP address. 0.0.0.0/0 means all.
Source Port	Enter the TCP or UDP port from which incoming packets are forwarded. Range: 1-65535.
Destination IP	Enter the IP address that packets are forwarded to after being received on the incoming interface.
Destination Port	Enter the TCP or UDP port that packets are forwarded to after being received on the incoming port(s). Range: 1-65535.
Protocol	Select from "TCP" and "UDP" as your application required.
Description	The description of this rule.

Table 4-3-2-3 Port Mapping Parameters

Related Configuration Example

[NAT Application Example](#)

4.3.2.4 MAC Binding

MAC Binding is used for specifying hosts by matching MAC addresses and IP addresses that are in the list of allowed outer network access.




Figure 4-3-2-4

MAC Binding List	
Item	Description
MAC Address	Set the binding MAC address.
IP Address	Set the binding IP address.
Description	Fill in a description for convenience of recording the meaning of the binding rule for each piece of MAC-IP.

Table 4-3-2-4 MAC Binding Parameters

4.3.3 QoS

Quality of service (QoS) refers to traffic prioritization and resource reservation control mechanisms rather than the achieved service quality. QoS is engineered to provide different priority for different applications, users, data flows, or to guarantee a certain level of performance to a data flow.




Figure 4-3-3-1

QoS	
Item	Description

Download/Upload	
Enable	Enable or disable QoS.
Default Class	Select default class from Service Class list.
Download/Upload Bandwidth Capacity	The download/upload bandwidth capacity of the network that the gateway is connected with, in kbps. Range: 1-8000000.
Service Classes	
Name	Give the service class a descriptive name.
Percent (%)	The amount of bandwidth that this class should be guaranteed in percentage. Range: 0-100.
Max BW(kbps)	The maximum bandwidth that this class is allowed to consume, in kbps. The value should be less than the "Download/Upload Bandwidth Capacity".
Min BW(kbps)	The minimum bandwidth that can be guaranteed for the class, in kbps. The value should be less than the "MAX BW" value.
Classification Rules	
Item	Description
Name	Give the rule a descriptive name.
Source IP	Source address of flow control (leaving it blank means any).
Source Port	Source port of flow control. Range: 0-65535 (leaving it blank means any).
Destination IP	Destination address of flow control (leaving it blank means any).
Destination Port	Destination port of flow control. Range: 0-65535 (leaving it blank means any).
Protocol	Select protocol from "ANY", "TCP", "UDP", "ICMP", and "GRE".
Service Class	Set service class for the rule.

Table 4-3-3-1 QoS (Download/Upload) Parameters

4.3.4 DHCP

DHCP adopts Client/Server communication mode. The Client sends configuration request to the Server which feeds back corresponding configuration information and distributes IP address to the Client so as to achieve the dynamic configuration of IP address and other information.

4.3.4.1 DHCP Server

The UG87-LW can be set as a DHCP server to distribute IP address when a host logs on and ensures each host is supplied with different IP addresses. DHCP Server has simplified some previous network management tasks requiring manual operations to the largest extent.




Figure 4-3-4-1

DHCP Server		
Item	Description	Default
Enable	Enable or disable DHCP server.	Enable
Interface	Select interface, e.g. GE.	GE
Start Address	Define the beginning of the pool of IP addresses which will be leased to DHCP clients.	192.168.1.100
End Address	Define the end of the pool of IP addresses which will be leased to DHCP clients.	192.168.1.199
Netmask	Define the subnet mask of IP address obtained by DHCP clients from DHCP server.	255.255.255.0
Lease Time (Min)	Set the lease time on which the client can use the IP address obtained from DHCP server. Range: 1-10080.	1440
Primary DNS Server	Set the primary DNS server.	114.114.114.114
Secondary DNS Server	Set the secondary DNS server.	Null
Windows Name Server	Define the Windows Internet Naming Service obtained by DHCP clients from DHCP sever. Generally you can leave it blank.	Null
Static IP		
MAC Address	Set a static and specific MAC address for the DHCP client (it should be different from other MACs so as to avoid conflict).	Null
IP Address	Set a static and specific IP address for the DHCP client (it should be outside of the DHCP range).	Null

Table 4-3-4-1 DHCP Server Parameters

4.3.4.2 DHCP Relay

The UG87-LW can be set as DHCP Relay to provide a relay tunnel to solve the problem that DHCP Client and DHCP Server are not in the same subnet.

Figure 4-3-4-2

DHCP Relay	
Item	Description
Enable	Enable or disable DHCP relay.
DHCP Server	Set DHCP server, up to 10 servers can be configured; separate them by blank space or ",".

Table 4-3-4-2 DHCP Relay Parameters

4.3.5 DDNS

Dynamic DNS (DDNS) is a method that automatically updates a name server in the Domain Name System, which allows user to alias a dynamic IP address to a static domain name. DDNS serves as a client tool and needs to coordinate with DDNS server. Before starting configuration, user shall register on a website of proper domain name provider and apply for a domain name.

Figure 4-3-5-1

DDNS	
Item	Description
Name	Give the DDNS a descriptive name.
Interface	Set interface bundled with the DDNS.
Service Type	Select the DDNS service provider.
Username	Enter the username for DDNS register.
User ID	Enter User ID of the custom DDNS server.
Password	Enter the password for DDNS register.
Server	Enter the name of DDNS server.

Hostname	Enter the hostname for DDNS.
Append IP	Append your current IP to the DDNS server update path.

Table 4-3-5-1 DDNS Parameters

4.3.6 Link Failover

This section describes how to configure link failover strategies, such as VRRP strategies.

Configuration Steps

1. Define one or more SLA operations (ICMP probe).
2. Define one or more track objects to track the status of SLA operation.
3. Define applications associated with track objects, such as VRRP or static routing.

4.3.6.1 SLA

SLA setting is used for configuring link probe method. The default probe type is ICMP.



Figure 4-3-6-1

SLA		
Item	Description	Default
ID	SLA index. Up to 10 SLA settings can be added. Range: 1-10.	1
Type	ICMP-ECHO is the default type to detect if the link is alive.	icmp-echo
Destination Address	The detected IP address.	114.114.114.114
Secondary Destination Address	The secondary detected IP address.	8.8.8.8
Data Size	User-defined data size. Range: 0-1000.	56
Interval (s)	User-defined detection interval. Range: 1-608400.	30
Timeout (ms)	User-defined timeout for response to determine ICMP detection failure. Range: 1-300000.	5000
PING Times	Define PING packet numbers in each SLA probe. Range: 1-1000.	5
Packet Loss Rate	Define packet loss rate in each SLA probe. SLA probe fails when the preset packet loss rate is	20

	exceeded.	
Start Time	Detection start time; select from "Now" and blank character. Blank character means this SLA detection doesn't start.	now

Table 4-3-6-1 SLA Parameters

4.3.6.2 Track

Track setting is designed for achieving linkage among SLA module, Track module and Application module. Track setting is located between application module and SLA module with main function of shielding the differences of various SLA modules and providing unified interfaces for application module.

Linkage between Track Module and SLA module

Once you complete the configuration, the linkage relationship between Track module and SLA module will be established. SLA module is used for detection of link status, network performance and notification of Track module. The detection results help track status change timely.

- For successful detection, the corresponding track item is Positive.
- For failed detection, the corresponding track item is Negative.

Linkage between Track Module and Application Module

After configuration, the linkage relationship between Track module and Application module will be established. When any change occurs in track item, a notification that requires corresponding treatment will be sent to Application module.

Currently, the application modules like VRRP and static routing can get linkage with track module.

If it sends an instant notification to Application module, the communication may be interrupted in some circumstances due to routing's failure like timely restoration or other reasons. Therefore, user can set up a period of time to delay notifying application module when the track item status changes.

ID	Type	SLA ID	Interface	Negative Delay(s)	Positive Delay(s)	Operation
1	sla	1	cellular0	0	1	✕
+						

Figure 4-3-6-2

Item	Description	Default
Index	Track index. Up to 10 track settings can be configured. Range: 1-10.	1
Type	The options are "sla" and "interface".	SLA

SLA ID	Defined SLA ID.	1
Interface	Select the interface whose status will be detected.	cellular0
Negative Delay (s)	When interface is down or SLA probing fails, it will wait according to the time set here before actually changing its status to Down. Range: 0-180 (0 refers to immediate switching).	0
Positive Delay (s)	When failure recovery occurs, it will wait according to the time set here before actually changing its status to Up. Range: 0-180 (0 refers to immediate switching).	1

Table 4-3-6-2 Track Parameters

4.3.6.3 VRRP

The Virtual Router Redundancy Protocol (VRRP) is a computer networking protocol that provides automatic assignment of available Internet Protocol (IP) routers for participating hosts. This increases the availability and reliability of routing paths via automatic default gateway selections in an IP sub-network.




Figure 4-3-6-3

VRRP		
Item	Description	Default
Enable	Enable or disable VRRP.	Disable
Interface	Select the interface of Virtual Router.	None
Virtual Router ID	User-defined Virtual Router ID. Range: 1-255.	None
Virtual IP	Set the IP address of Virtual Router.	None

Priority	The VRRP priority range is 1-254 (a bigger number indicates a higher priority). The router with higher priority will be more likely to become the gateway router.	100
Advertisement Interval (s)	Heartbeat package transmission time interval between routers in the virtual ip group. Range: 1-255.	1
Preemption Mode	If the gateway works in the preemption mode, once it finds that its own priority is higher than that of the current gateway router, it will send VRRP notification package, resulting in re-election of gateway router and eventually replacing the original gateway router. Accordingly, the original gateway router will become a Backup router.	Disable
Track ID	Trace detection, select the defined track ID or blank character.	None

Table 4-3-6-3 VRRP Parameters

4.3.6.4 WAN Failover

WAN failover refers to failover between Ethernet WAN interface and cellular interface. When service transmission can't be carried out normally due to malfunction of a certain interface or lack of bandwidth, the rate of flow can be switched to backup interface quickly. Then the backup interface will carry out service transmission and share network flow so as to improve reliability of communication of data equipment.

When link state of main interface is switched from up to down, system will have the pre-set delay works instead of switching to link of backup interface immediately. Only if the state of main interface is still down after delay, will the system switch to link of backup interface. Otherwise, system will remain unchanged.




Figure 4-3-6-4

WAN Failover		
Parameters	Description	Default
Main Interface	Select a link interface as the main link.	Cellular0
Backup Interface	Select a link interface as the backup link.	GEO
Startup Delay (s)	Set how long to wait for the startup tracking detection policy to take effect. Range: 0-300.	3
Up Delay (s)	When the primary interface switches from failed detection to successful detection, switching can be delayed based on the set time. Range: 0-180 (0 refers to immediate switching).	0
Down Delay (s)	When the primary interface switches from successful detection to failed detection, switching can be delayed based on the set time. Range: 0-180 (0 refers to immediate switching).	0
Track ID	Track detection, select the defined track ID.	1

Table 4-3-6-4 WAN Failover Parameters

4.3.7 VPN

Virtual Private Networks, also called VPNs, are used to securely connect two private networks together so that devices can connect from one network to the other network via secure channels.

The UG87-LW supports DMVPN, IPsec, GRE, L2TP, PPTP, OpenVPN, as well as GRE over IPsec and L2TP over IPsec.

4.3.7.1 DMVPN

A dynamic multi-point virtual private network (DMVPN), combining mGRE and IPsec, is a secure network that exchanges data between sites without passing traffic through an organization's headquarter VPN server or gateway.



For your device security

Status

LoRaWAN

Network

Interface

Firewall

QoS

DHCP

DDNS

Link Failover

VPN

System

Industrial

Maintenance

DMVPN
IPsec
GRE
L2TP
PPTP

DMVPN Settings

Enable

Hub Address

Local IP Address

GRE HUB IP Address

GRE Local IP Address

GRE Mask

GRE Key

Negotiation Mode

Authentication Algorithm

Encryption Algorithm

DH Group

Key

Local ID Type

IKE Life Time(s)

SA Algorithm

PFS Group

Life Time(s)

Figure 4-3-7-1

VPN

System

Industrial

DPD Time Interval(s)

DPD Timeout(s)

Cisco Secret

NHRP Holdtime(s)

Figure 4-3-7-2

DMVPN	
Item	Description
Enable	Enable or disable DMVPN.
Hub Address	The IP address or domain name of DMVPN Hub.
Local IP address	DMVPN local tunnel IP address.
GRE Hub IP Address	GRE Hub tunnel IP address.
GRE Local IP Address	GRE local tunnel IP address.
GRE Netmask	GRE local tunnel netmask.
GRE Key	GRE tunnel key.

Negotiation Mode	Select from "Main" and "Aggressive".
Authentication Algorithm	Select from "DES", "3DES", "AES128", "AES192" and "AES256".
Encryption Algorithm	Select from "MD5" and "SHA1".
DH Group	Select from "MODP768_1", "MODP1024_2" and "MODP1536_5".
Key	Enter the preshared key.
Local ID Type	Select from "Default", "ID", "FQDN", and "User FQDN"
IKE Life Time (s)	Set the lifetime in IKE negotiation. Range: 60-86400.
SA Algorithm	Select from "DES_MD5", "DES_SHA1", "3DES_MD5", "3DES_SHA1", "AES128_MD5", "AES128_SHA1", "AES192_MD5", "AES192_SHA1", "AES256_MD5" and "AES256_SHA1".
PFS Group	Select from "NULL", "MODP768_1", "MODP1024_2" and "MODP1536-5".
Life Time (s)	Set the lifetime of IPsec SA. Range: 60-86400.
DPD Interval Time (s)	Set DPD interval time
DPD Timeout (s)	Set DPD timeout.
Cisco Secret	Cisco Nhrp key.
NHRP Holdtime (s)	The holdtime of Nhrp protocol.

Table 4-3-7-1 DMVPN Parameters

4.3.7.2 IPsec

IPsec is especially useful for implementing virtual private networks and for remote user access through dial-up connection to private networks. A big advantage of IPsec is that security arrangements can be handled without requiring changes to individual user computers.

IPsec provides three choices of security service: Authentication Header (AH), Encapsulating Security Payload (ESP), and Internet Key Exchange (IKE). AH essentially allows authentication of the senders' data. ESP supports both authentication of the sender and data encryption. IKE is used for cipher code exchange. All of them can protect one and more data flows between hosts, between host and gateway, and between gateways.

The screenshot shows the IPsec configuration interface. At the top, there are navigation tabs: DMVPN, IPsec (highlighted), GRE, L2TP, and PPTP. Below the tabs is the 'IPsec Settings' section. A sub-section titled 'IPsec_1' contains the following settings:

- Enable:** A checkbox that is checked.
- IPsec Gateway Address:** An empty text input field.
- IPsec Mode:** A dropdown menu with 'Tunnel' selected.
- IPsec Protocol:** A dropdown menu with 'ESP' selected.
- Local Subnet:** An empty text input field.
- Local Subnet Mask:** An empty text input field.
- Local ID Type:** A dropdown menu with 'Default' selected.
- Remote Subnet:** An empty text input field.
- Remote Subnet Mask:** An empty text input field.
- Remote ID Type:** A dropdown menu with 'Default' selected.

Figure 4-3-7-3

IPsec	
Item	Description
Enable	Enable IPsec tunnel. A maximum of 3 tunnels is allowed.
IPsec Gateway Address	Enter the IP address or domain name of remote IPsec server.
IPsec Mode	Select from "Tunnel" and "Transport".
IPsec Protocol	Select from "ESP" and "AH".
Local Subnet	Enter the local subnet IP address that IPsec protects.
Local Subnet Netmask	Enter the local netmask that IPsec protects.
Local ID Type	Select from "Default", "ID", "FQDN", and "User FQDN".
Remote Subnet	Enter the remote subnet IP address that IPsec protects.
Remote Subnet Mask	Enter the remote netmask that IPsec protects.
Remote ID type	Select from "Default", "ID", "FQDN", and "User FQDN".

Table 4-3-7-2 IPsec Parameters

IKE Parameter	<input checked="" type="checkbox"/>
IKE Version	IKEv1
Negotiation Mode	Main
Encryption Algorithm	DES
Authentication Algorithm	MD5
DH Group	MODP768-1
Local Authentication	PSK
Local Secrets	
XAUTH	<input type="checkbox"/>
Lifetime(s)	10800
SA Parameter	<input checked="" type="checkbox"/>
SA Algorithm	DES-MD5
PFS Group	NULL
Lifetime(s)	3600
DPD Time Interval(s)	30
DPD Timeout(s)	150
IPsec Advanced	<input checked="" type="checkbox"/>
Enable Compression	<input type="checkbox"/>
VPN Over IPsec Type	NONE

Figure 4-3-7-4

IKE Parameter	
Item	Description
IKE Version	Select from "IKEv1" and "IKEv2".
Negotiation Mode	Select from "Main" and "Aggressive".
Encryption Algorithm	Select from "DES", "3DES", "AES128", "AES192" and "AES256".
Authentication Algorithm	Select from "MD5" and "SHA1"
DH Group	Select from "MODP768_1", "MODP1024_2" and "MODP1536_5".
Local Authentication	Select from "PSK" and "CA".
Local Secrets	Enter the preshared key.
XAUTH	Enter XAUTH username and password after XAUTH is enabled.
Lifetime (s)	Set the lifetime in IKE negotiation. Range: 60-86400.
SA Parameter	
SA Algorithm	Select from "DES_MD5", "DES_SHA1", "3DES_MD5", "3DES_SHA1", "AES128_MD5", "AES128_SHA1", "AES192_MD5", "AES192_SHA1", "AES256_MD5" and "AES256_SHA1".
PFS Group	Select from "NULL", "MODP768_1", "MODP1024_2" and "MODP1536_5".
Lifetime (s)	Set the lifetime of IPsec SA. Range: 60-86400.

DPD Interval Time(s)	Set DPD interval time to detect if the remote side fails.
DPD Timeout(s)	Set DPD timeout. Range: 10-3600.
IPsec Advanced	
Enable Compression	The head of IP packet will be compressed after it's enabled.
VPN Over IPsec Type	Select from "NONE", "GRE" and "L2TP" to enable VPN over IPsec function.

Table 4-3-7-3 IPsec Parameters

4.3.7.3 GRE

Generic Routing Encapsulation (GRE) is a protocol that encapsulates packets in order to route other protocols over IP networks. It's a tunneling technology that provides a channel through which encapsulated data message can be transmitted and encapsulation and decapsulation can be realized at both ends.

In the following circumstances the GRE tunnel transmission can be applied:

- GRE tunnel can transmit multicast data packets as if it were a true network interface. Single use of IPsec cannot achieve the encryption of multicast.
- A certain protocol adopted cannot be routed.
- A network of different IP addresses shall be required to connect other two similar networks.

The screenshot displays the 'GRE Settings' configuration page. At the top, there are tabs for 'DMVPN', 'IPsec', 'GRE' (selected), 'L2TP', and 'PPTP'. Below the tabs, the 'GRE Settings' section is visible, containing a sub-section for 'GRE_1'. The configuration options include:

- Enable:** A checked checkbox.
- Remote IP Address:** An empty text input field.
- Local IP Address:** An empty text input field.
- Local Virtual IP Address:** An empty text input field.
- Netmask:** A text input field containing '255.255.255.0'.
- Peer Virtual IP Address:** An empty text input field.
- Global Traffic Forwarding:** An unchecked checkbox.
- Remote Subnet:** An empty text input field.
- Remote Netmask:** An empty text input field.
- MTU:** A text input field containing '1500'.
- Key:** An empty text input field.
- Enable NAT:** A checked checkbox.

Figure 4-3-7-5

GRE	
Item	Description
Enable	Check to enable GRE function.

Remote IP Address	Enter the real remote IP address of GRE tunnel.
Local IP Address	Set the local IP address.
Local Virtual IP Address	Set the local tunnel IP address of GRE tunnel.
Netmask	Set the local netmask.
Peer Virtual IP Address	Enter remote tunnel IP address of GRE tunnel.
Global Traffic Forwarding	All the data traffic will be sent out via GRE tunnel when this function is enabled.
Remote Subnet	Enter the remote subnet IP address of GRE tunnel.
Remote Netmask	Enter the remote netmask of GRE tunnel.
MTU	Enter the maximum transmission unit. Range: 64-1500.
Key	Set GRE tunnel key.
Enable NAT	Enable NAT traversal function.

Table 4-3-7-4 GRE Parameters

4.3.7.4 L2TP

Layer Two Tunneling Protocol (L2TP) is an extension of the Point-to-Point Tunneling Protocol (PPTP) used by an Internet service provider (ISP) to enable the operation of a virtual private network (VPN) over the Internet.




Figure 4-3-7-6

L2TP	
Item	Description
Enable	Check to enable L2TP function.
Remote IP Address	Enter the public IP address or domain name of L2TP server.
Username	Enter the username that L2TP server provides.
Password	Enter the password that L2TP server provides.
Authentication	Select from "Auto", "PAP", "CHAP", "MS-CHAPv1" and

	"MS-CHAPv2".
Global Traffic Forwarding	All of the data traffic will be sent out via L2TP tunnel after this function is enabled.
Remote Subnet	Enter the remote IP address that L2TP protects.
Remote Subnet Mask	Enter the remote netmask that L2TP protects.
Key	Enter the password of L2TP tunnel.

Table 4-3-7-5 L2TP Parameters

Figure 4-3-7-7

Advanced Settings	
Item	Description
Local IP Address	Set tunnel IP address of L2TP client. Client will obtain tunnel IP address automatically from the server when it's null.
Peer IP Address	Enter tunnel IP address of L2TP server.
Enable NAT	Enable NAT traversal function.
Enable MPPE	Enable MPPE encryption.
Address/Control Compression	For PPP initialization. User can keep the default option.
Protocol Field Compression	For PPP initialization. User can keep the default option.
Asyncmap Value	One of the PPP protocol initialization strings. User can keep the default value. Range: 0-ffffff.
MRU	Set the maximum receive unit. Range: 64-1500.
MTU	Set the maximum transmission unit. Range: 64-1500
Link Detection Interval (s)	Set the link detection interval time to ensure tunnel connection. Range: 0-600.
Max Retries	Set the maximum times of retry to detect the L2TP connection

	failure. Range: 0-10.
Expert Options	User can enter some other PPP initialization strings in this field and separate the strings with blank space.

Table 4-3-7-6 L2TP Parameters

4.3.7.5 PPTP

Point-to-Point Tunneling Protocol (PPTP) is a protocol that allows corporations to extend their own corporate network through private "tunnels" over the public Internet. Effectively, a corporation uses a wide-area network as a single large local area network.




Figure 4-3-7-8

PPTP	
Item	Description
Enable	Enable PPTP client. A maximum of 3 tunnels is allowed.
Remote IP Address	Enter the public IP address or domain name of PPTP server.
Username	Enter the username that PPTP server provides.
Password	Enter the password that PPTP server provides.
Authentication	Select from "Auto", "PAP", "CHAP", "MS-CHAPv1", and "MS-CHAPv2".
Global Traffic Forwarding	All of the data traffic will be sent out via PPTP tunnel once enable this function.
Remote Subnet	Set the peer subnet of PPTP.
Remote Subnet Mask	Set the netmask of peer PPTP server.

Table 4-3-7-7 PPTP Parameters

Advanced Settings	<input checked="" type="checkbox"/>
Local IP Address	<input type="text"/>
Peer IP Address	<input type="text"/>
Enable NAT	<input checked="" type="checkbox"/>
Enable MPPE	<input checked="" type="checkbox"/>
Address/Control Compression	<input type="checkbox"/>
Protocol Field Compression	<input type="checkbox"/>
Asyncmap Value	<input type="text" value="ffffff"/>
MRU	<input type="text" value="1500"/>
MTU	<input type="text" value="1500"/>
Link Detection Interval(s)	<input type="text" value="60"/>
Max Retries	<input type="text" value="0"/>
Expert Options	<input type="text"/>

Figure 4-3-7-9

PPTP Advanced Settings	
Item	Description
Local IP Address	Set IP address of PPTP client.
Peer IP Address	Enter tunnel IP address of PPTP server.
Enable NAT	Enable the NAT function of PPTP.
Enable MPPE	Enable MPPE encryption.
Address/Control Compression	For PPP initialization. User can keep the default option.
Protocol Field Compression	For PPP initialization. User can keep the default option.
Asyncmap Value	One of the PPP protocol initialization strings. User can keep the default value. Range: 0-ffffff.
MRU	Enter the maximum receive unit. Range: 0-1500.
MTU	Enter the maximum transmission unit. Range: 0-1500.
Link Detection Interval (s)	Set the link detection interval time to ensure tunnel connection. Range: 0-600.
Max Retries	Set the maximum times of retrying to detect the PPTP connection failure. Range: 0-10.
Expert Options	User can enter some other PPP initialization strings in this field and separate the strings with blank space.

Table 4-3-7-8 PPTP Parameters

Related Configuration Example

[PPTP Application Example](#)

4.3.7.6 OpenVPN Client

OpenVPN is an open source virtual private network (VPN) product that offers a simplified security framework, modular network design, and cross-platform portability.

Advantages of OpenVPN include:

- Security provisions that function against both active and passive attacks.
- Compatibility with all major operating systems.
- High speed (1.4 megabytes per second typically).
- Ability to configure multiple servers to handle numerous connections simultaneously.
- All encryption and authentication features of the OpenSSL library.
- Advanced bandwidth management.
- A variety of tunneling options.
- Compatibility with smart cards that support the Windows Crypt application program interface (API).




Figure 4-3-7-10

OpenVPN Client	
Item	Description
Enable	Enable OpenVPN client. A maximum of 3 tunnels is allowed.

Protocol	Select from "UDP" and "TCP".
Remote IP Address	Enter remote OpenVPN server's IP address or domain name.
Port	Enter the listening port number of remote OpenVPN server. Range: 1-65535.
Interface	Select from "tun" and "tap".
Authentication	Select from "None", "Pre-shared", "Username/Password", "X.509 cert", and "X.509 cert+user".
Local Tunnel IP	Set local tunnel address.
Remote Tunnel IP	Enter remote tunnel address.
Global Traffic Forwarding	All the data traffic will be sent out via OpenVPN tunnel when this function is enabled.
Enable TLS Authentication	Check to enable TLS authentication.
Username	Enter username provided by OpenVPN server.
Password	Enter password provided by OpenVPN server.
Enable NAT	Enable NAT traversal function.
Compression	Select LZO to compress data.
Link Detection Interval (s)	Set link detection interval time to ensure tunnel connection. Range: 10-1800.
Link Detection Timeout (s)	Set link detection timeout. OpenVPN will be reestablished after timeout. Range: 60-3600.
Cipher	Select from "NONE", "BF-CBC", "DE-CBC", "DES-EDE3-CBC", "AES-128-CBC", "AES-192-CBC" and "AES-256-CBC".
MTU	Enter the maximum transmission unit. Range: 128-1500.
Max Frame Size	Set the maximum frame size. Range: 128-1500.
Verbose Level	Select from "ERROR", "WARNING", "NOTICE" and "DEBUG".
Expert Options	User can enter some other PPP initialization strings in this field and separate the strings with blank space.
Local Route	
Subnet	Set the local route's IP address.
Subnet Mask	Set the local route's netmask.

Table 4-3-7-9 OpenVPN Client Parameters

4.3.7.7 OpenVPN Server

The UG87-LW supports OpenVPN server to create secure point-to-point or site-to-site connections in routed or bridged configurations and remote access facilities.

DMVPN IPsec GRE L2TP PPTP OpenVPN Client **OpenVPN Server**

OpenVPN Server Settings

Enable

Protocol

Port

Listening IP

Interface

Authentication

Local Virtual IP

Remote Virtual IP

Enable NAT

Compression

Link Detection Interval

Cipher

MTU

Max Frame Size

Verbose Level

Expert Options

Figure 4-3-7-11

Local Route

Subnet	Netmask	Operation
		+

Account

Username	Password	Operation
		+

Figure 4-3-7-12

OpenVPN Server	
Item	Description
Enable	Enable/disable OpenVPN server.
Protocol	Select from TCP and UDP.
Port	Fill in listening port number. Range: 1-65535.
Listening IP	Enter WAN IP address or LAN IP address. Leaving it blank refers to all active WAN IP and LAN IP address.
Interface	Select from " tun" and "tap".
Authentication	Select from "None", "Pre-shared", "Username/Password", "X.509 cert" and "X. 509 cert +user".
Local Virtual IP	The local tunnel address of OpenVPN's tunnel.

Remote Virtual IP	The remote tunnel address of OpenVPN's tunnel.
Client Subnet	Local subnet IP address of OpenVPN client.
Client Netmask	Local netmask of OpenVPN client.
Renegotiation Interval(s)	Set interval for renegotiation. Range: 0-86400.
Max Clients	Maximum OpenVPN client number. Range: 1-128.
Enable CRL	Enable CRL
Enable Client to Client	Allow access between different OpenVPN clients.
Enable Dup Client	Allow multiple users to use the same certification.
Enable NAT	Check to enable the NAT traversal function.
Compression	Select "LZO" to compress data.
Link Detection Interval	Set link detection interval time to ensure tunnel connection. Range: 10-1800.
Cipher	Select from "NONE", "BF-CBC", "DES-CBC", "DES-EDE3-CBC", "AES-128-CBC", "AES-192-CBC" and "AES-256-CBC".
MTU	Enter the maximum transmission unit. Range: 64-1500.
Max Frame Size	Set the maximum frame size. Range: 64-1500.
Verbose Level	Select from "ERROR", "WARNING", "NOTICE" and "DEBUG".
Expert Options	User can enter some other PPP initialization strings in this field and separate the strings with blank space.
Local Route	
Subnet	The real local IP address of OpenVPN client.
Netmask	The real local netmask of OpenVPN client.
Account	
Username & Password	Set username and password for OpenVPN client.

Table 4-3-7-10 OpenVPN Server Parameters

4.3.7.8 Certifications

User can import/export certificate and key files for OpenVPN and IPsec on this page.




Figure 4-3-7-13

OpenVPN Client	
Item	Description

CA	Import/Export CA certificate file.
Public Key	Import/Export public key file.
Private Key	Import/Export private key file.
TA	Import/Export TA key file.
Preshared Key	Import/Export static key file.
PKCS12	Import/Export PKCS12 certificate file.

Table 4-3-7-11 OpenVPN Client Certification Parameters

The screenshot shows the 'OpenVPN Server' configuration page. It features a list of parameters on the left, each with an empty text input field, a blue 'Browse' button, and three grey buttons labeled 'Import', 'Export', and 'Delete'.

Parameter	File Selection	Import	Export	Delete
CA	<input type="text"/> Browse	Import	Export	Delete
Public Key	<input type="text"/> Browse	Import	Export	Delete
Private Key	<input type="text"/> Browse	Import	Export	Delete
DH	<input type="text"/> Browse	Import	Export	Delete
TA	<input type="text"/> Browse	Import	Export	Delete
CRL	<input type="text"/> Browse	Import	Export	Delete
Preshared Key	<input type="text"/> Browse	Import	Export	Delete

Figure 4-3-7-14

OpenVPN Server	
Item	Description
CA	Import/Export CA certificate file.
Public Key	Import/Export public key file.
Private Key	Import/Export private key file.
DH	Import/Export DH key file.
TA	Import/Export TA key file.
CRL	Import/Export CRL.
Preshared Key	Import/Export static key file.

Table 4-3-7-12 OpenVPN Server Parameters

The screenshot shows the 'IPsec' configuration page for a specific instance named 'IPsec_1'. It features a list of parameters on the left, each with an empty text input field, a blue 'Browse' button, and three grey buttons labeled 'Import', 'Export', and 'Delete'.

Parameter	File Selection	Import	Export	Delete
CA	<input type="text"/> Browse	Import	Export	Delete
Client Key	<input type="text"/> Browse	Import	Export	Delete
Server Key	<input type="text"/> Browse	Import	Export	Delete
Private Key	<input type="text"/> Browse	Import	Export	Delete
CRL	<input type="text"/> Browse	Import	Export	Delete

Figure 4-3-7-15

IPsec	
Item	Description
CA	Import/Export CA certificate.
Client Key	Import/Export client key.
Server Key	Import/Export server key.
Private Key	Import/Export private key.
CRL	Import/Export certificate recovery list.

Table 4-3-7-13 IPsec Parameters

4.4 System

This section describes how to configure general settings, such as administration account, access service, system time, common user management, SNMP, AAA, event alarms, etc.

4.4.1 General Settings

4.4.1.1 General

General settings include system info, access service and HTTPS certificates.

Service	Port	Local	Remote
HTTP	80	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>
HTTPS	443	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>
TELNET	23	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>
SSH	22	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>

Figure 4-4-1-1

General		
Item	Description	Default
System		
Hostname	User-defined gateway name, needs to start with a letter.	URSA
Web Login Timeout (s)	You need to log in again if it times out. Range: 100-3600.	1800
Access Service		
Local	Access the gateway locally.	Enable

Port	Set port number of the services. Range: 1-65535.	--
Remote	Access the gateway remotely.	Disable
HTTP	Users can log in the device locally via HTTP to access and control it through Web after the option is checked.	80
HTTPS	Users can log in the device locally and remotely via HTTPS to access and control it through Web after option is checked.	8088
TELNET		8023
SSH	Users can log in the device locally and remotely via SSH after the option is checked.	8022
HTTPS Certificates		
Certificate	Click "Browse" button, choose certificate file on the PC, and then click "Import" button to upload the file into gateway. Click "Export" button will export the file to the PC. Click "Delete" button will delete the file.	--
Key	Click "Browse" button, choose key file on the PC, and then click "Import" button to upload the file into gateway. Click "Export" button will export file to the PC. Click "Delete" button will delete the file.	--

Table 4-3-1-1 General Setting Parameters

4.4.1.2 Account Management

Here you can change the login username and password of the administrator.

Note: it is strongly recommended that you modify them for the sake of security.

The screenshot shows a web interface with a navigation bar containing tabs: General, Account (selected), System Time, SMTP, Phone, and Storage. Below the navigation bar, there is a section titled 'Change Account Info' with four input fields: Username (containing 'admin'), Old Password, New Password, and Confirm New Password.

Figure 4-4-1-2

Account	
Item	Description
Username	Enter a new username. You can use characters such as a-z, 0-9, "_", "-", "\$". The first character can't be a digit.
Old Password	Enter the old password.
New Password	Enter a new password.
Confirm New Password	Enter the new password again.

Table 4-4-1-2 Account Information

Related Configuration Example

[Account Info Management](#)

4.4.1.3 System Time

This section explains how to set the system time including time zone and time synchronization type.

Note: to ensure that the gateway runs with the correct time, it's recommended that you set the system time when configuring the gateway.




Figure 4-4-1-3




Figure 4-4-1-4




Figure 4-4-1-5

System Time	
Item	Description

Current Time	Show the current system time.
Time Zone	Click the drop down list to select the time zone you are in.
Sync Type	Click the drop down list to select the time synchronization type.
Sync with Browser	Synchronize time with browser.
Browser Time	Show the current time of browser.
Set up Manually	Manually configure the system time.
Sync with NTP Server	Synchronize time with NTP server so as to achieve time synchronization of all devices equipped with a clock on network.
Sync with NTP Server	
NTP Server Address	Set NTP server address (domain name/IP).
Enable NTP Server	NTP client on the network can achieve time synchronization with gateway after "Enable NTP Server" option is checked.

Table 4-4-1-3 System Time Parameters

Related Configuration Example

[System Time Management](#)

4.4.1.4 SMTP

SMTP, short for Simple Mail Transfer Protocol, is a TCP/IP protocol used in sending and receiving e-mail. This section describes how to configure email settings.

Figure 4-4-1-6

SMTP	
Item	Description
SMTP Client Settings	
Enable	Enable or disable SMTP client function.

Email Address	Enter the sender's email account.
Password	Enter the sender's email password.
SMTP Server Address	Enter SMTP server's domain name.
Port	Enter SMTP server port. Range: 1-65535.
Enable TLS	Enable or disable TLS encryption.
Email Recipients	
Email Address	Add recipients' email address.
Test	Check if the recipients can get the mail from sender.

Table 4-4-1-4 SMTP Setting

Related Topics

[Events Setting](#)

[Events Application Example](#)

4.4.1.5 Phone

Phone settings involve in call/SMS trigger and SMS alarm for events.

1. Add phone list.
2. Select phone numbers and add them to the phone group.
3. Go to “Network > Interface > Cellular > Connection Mode > Connect on Demand > Trigger by Call / Trigger by SMS” or go to “System > Events > Event Settings > SMS” and then select the phone group ID.




Figure 4-4-1-7

Phone	
Item	Description
Phone Number List	
Number	Enter the telephone number. Digits, "+" and "-" are allowed.
Description	The description of the telephone number.
Phone Group	
Group ID	Set number for phone group. Range: 1-100.
Description	The description of the phone group.
List	Show the phone list.
Selected	Show the selected phone number.

Table 4-4-1-5 Phone Settings

Related Topic

[Connect on Demand](#)

4.4.2 User Management

This section describes how to create common user accounts.

The common user permission includes Read-Only and Read-Write.




Figure 4-4-2-1

User Management	
Item	Description
Username	Enter a new username. You can use characters such as a-z, 0-9, "_", "-", "\$". The first character can't be a digit.
Password	Set password.
Permission	Select user permission from "Read-Only" and "Read-Write". <ul style="list-style-type: none"> - Read-Only: users can only view the configuration of gateway in this level. - Read-Write: users can view and set the configuration of gateway in this level.

Table 4-4-2-1 User Management

Related Configuration Example

[Common User Management](#)

4.4.3 SNMP

SNMP is widely used in network management for network monitoring. SNMP exposes management data with variables form in managed system. The system is organized in a management information base (MIB) which describes the system status and configuration. These variables can be remotely queried by managing applications.

Configuring SNMP in networking, NMS, and a management program of SNMP should be set up at the Manager.

Configuration steps are listed as below for achieving query from NMS:

1. Enable SNMP setting.
2. Download MIB file and load it into NMS.
3. Configure MIB View.
4. Configure VCAM.

Related Configuration Example

[SNMP Application Example](#)

4.4.3.1 SNMP

The UG87-LW supports SNMPv1, SNMPv2c and SNMPv3 version. SNMPv1 and SNMPv2c employ community name authentication. SNMPv3 employs authentication encryption by username and password.

Figure 4-4-3-1

SNMP Settings	
Item	Description
Enable	Enable or disable SNMP function.
Port	Set SNMP listened port. Range: 1-65535. The default port is 161.

SNMP Version	Select SNMP version; support SNMP v1/v2c/v3.
Location Information	Fill in the location information.
Contact Information	Fill in the contact information.

Table 4-4-3-1 SNMP Parameters

4.4.3.2 MIB View

This section explains how to configure MIB view for the objects.

View Name	View Filter	View OID	Operation
All	Included	1	✕
system	Included	1.3.6.1.2.1.1	✕
			+

Figure 4-4-3-2

MIB View	
Item	Description
View Name	Set MIB view's name.
View Filter	Select from "Included" and "Excluded".
View OID	Enter the OID number.
Included	You can query all nodes within the specified MIB node.
Excluded	You can query all nodes except for the specified MIB node.

Table 4-3-3-2 MIB View Parameters

4.4.3.3 VACM

This section describes how to configure VACM parameters.

Community	Permission	MIB View	Network	Operation
private	Read-write	All	0.0.0.0/0	✕
public	Read-only	none	0.0.0.0/0	✕
				+

Figure 4-3-3-3

VACM	
Item	Description
SNMP v1 & v2 User List	
Community	Set the community name.
Permission	Select from "Read-Only" and "Read-Write".
MIB View	Select an MIB view to set permissions from the MIB view list.
Network	The IP address and bits of the external network accessing the MIB view.
Read-Write	The permission of the specified MIB node is read and write.
Read-Only	The permission of the specified MIB node is read only.
SNMP v3 User List	
Group Name	Set the name of SNMPv3 group.
Security Level	Select from "NoAuth/NoPriv", "Auth/NoPriv", and "Auth/Priv".
Read-Only View	Select an MIB view to set permission as "Read-only" from the MIB view list.
Read-Write View	Select an MIB view to set permission as "Read-write" from the MIB view list.
Inform View	Select an MIB view to set permission as "Inform" from the MIB view list.

Table 4-4-3-3 VACM Parameters

4.4.3.4 Trap

This section explains how to enable network monitoring by SNMP trap.

Figure 4-4-3-4

SNMP Trap	
Item	Description
Enable	Enable or disable SNMP Trap function.
SNMP Version	Select SNMP version; support SNMP v1/v2c/v3.
Server Address	Fill in NMS's IP address or domain name.
Port	Fill in UDP port. Port range is 1-65535. The default port is 162.
Name	Fill in the group name when using SNMP v1/v2c; fill in the username when using SNMP v3.
Auth/Priv Mode	Select from "NoAuth & No Priv", "Auth & NoPriv", and "Auth & Priv".

Table 4-4-3-4 Trap Parameters

4.4.3.5 MIB

This section describes how to download MIB files. The last MIB file “URSA-gateway-MIB.txt” is for the UG87-LW.




Figure 4-4-3-5

MIB	
Item	Description
MIB File	Select the MIB file you need.
Download	Click "Download" button to download the MIB file to PC.

Table 4-4-3-5 MIB Download

4.4.4 AAA

AAA access control is used for visitors control and the available corresponding services once access is allowed. It adopts the same method to configure three independent safety functions. It provides modularization methods for following services:

- Authentication: verify if the user is qualified to access to the network.
- Authorization: authorize related services available for the user.
- Charging: record the utilization of network resources.

4.4.4.1 RADIUS

Using UDP for its transport, RADIUS is generally applied in various network environments with higher requirements of security and permission of remote user access.




Figure 4-3-4-1

RADIUS	
Item	Description
Enable	Enable or disable RADIUS.
Server IP Address	Fill in the RADIUS server IP address/domain name.
Server Port	Fill in the RADIUS server port. Range: 1-65535.
Key	Fill in the key consistent with that of RADIUS server in order to get connected with RADIUS server.

Table 4-4-4-1 RADIUS Parameters

4.4.4.2 TACACS+

Using TCP for its transport, TACACS+ is mainly used for authentication, authorization and charging of the access users and terminal users by adopting PPP and VPDN.

Figure 4-3-4-2

TACACS+	
Item	Description
Enable	Enable or disable TACACS+.
Server IP Address	Fill in the TACACS+ server IP address/domain name.
Server Port	Fill in the TACACS+ server port. Range: 1-65535.
Key	Fill in the key consistent with that of TACACS+ server in order to get connected with TACACS+ server.

Table 4-3-4-2 TACACS+ Parameters

4.3.4.3 LDAP

A common usage of LDAP is to provide a central place to store usernames and passwords. This allows many different applications and services to connect the LDAP server to validate users.

LDAP is based on a simpler subset of the standards contained within the [X.500](#) standard. Because of this relationship, LDAP is sometimes called X.500-lite as well.

The screenshot shows the LDAP Settings configuration interface. It includes a navigation bar with tabs for Radius, Tacacs+, LDAP (active), and Authentication. Below the tabs, the 'LDAP Settings' section contains the following fields:

- Enable:** A checkbox that is checked.
- Server IP Address:** An empty text input field.
- Server Port:** A text input field containing the value '389'.
- Base DN:** An empty text input field.
- Security:** A dropdown menu currently set to 'None'.
- Username:** An empty text input field.
- Password:** An empty text input field.

Figure 4-3-4-3

LDAP	
Item	Description
Enable	Enable or Disable LDAP.
Server IP Address	Fill in the LDAP server's IP address/domain name. The maximum count is 10.
Server Port	Fill in the LDAP server's port. Range: 1-65535
Base DN	The top of LDAP directory tree.
Security	Select secure method from "None", "StartTLS" and "SSL".
Username	Enter the username to access the server.
Password	Enter the password to access the server.

Table 4-3-4-3 LDAP Parameters

4.3.4.4 Authentication

AAA supports the following authentication ways:

- None: uses no authentication, generally not recommended.
- Local: uses the local username database for authentication.
 - Advantages: rapidness, cost reduction.
 - Disadvantages: storage capacity limited by hardware.
- Remote: has user's information stored on authentication server. RADIUS, TACACS+ and LDAP supported for remote authentication.

When RADIUS, TACACS+, and local are configured at the same time, the priority level is: 1 > 2 > 3.

Service	1	2	3
Console	None ▼	None ▼	None ▼
Web	None ▼	None ▼	None ▼
Telnet	None ▼	None ▼	None ▼
SSH	None ▼	None ▼	None ▼

Figure 4-3-4-4

Authentication	
Item	Description
Console	Select authentication for Console access.
Web	Select authentication for Web access.
Telnet	Select authentication for Telnet access.
SSH	Select authentication for SSH access.

Table 4-3-4-4 Authentication Parameters

4.3.5 Device Management

You can connect the device to the DeviceHub on this page so as to manage the gateway centrally and remotely.

Figure 4-3-5-1

DeviceHub	
Item	Description
Status	Show the connection status between the gateway and the

	DeviceHub.
Disconnected	Click this button to disconnect the gateway from the DeviceHub.
Activation Server Address	IP address or domain of the DeviceHub.
DeviceHub Server Address	The URL address for the device to connect to the DeviceHub, e.g. http://220.82.63.79:8080/acs.
Activation Method	Select activation method to connect the gateway to the DeviceHub server, options are "By Authentication ID" and "By ID".
Authentication Code	Fill in the authentication code generated from the DeviceHub.
ID	Fill in the registered DeviceHub account (email) and password.
Password	

Table 4-3-5-1

4.3.6 Events

Event feature is capable of sending alerts by Email when certain system events occur.

4.3.6.1 Events

You can view alarm messages on this page.




Figure 4-3-6-1

Events	
Item	Description
Mark as Read	Mark the selected event alarm as read.
Delete	Delete the selected event alarm.
Mark All as Read	Mark all event alarms as read.
Delete All Alarms	Delete all event alarms.
Status	Show the reading status of the event alarms, such as "Read" and

	“Unread”.
Type	Show the event type that should be alarmed.
Time	Show the alarm time.
Message	Show the alarm content.

Table 4-3-6-1 Events Parameters

4.3.6.2 Events Settings

In this section, you can decide what events to record and whether you want to receive email and SMS notifications when any change occurs.

Events	Record	Email Email Setting	SMS SMS Setting
Cellular Up	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>
Cellular Down	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>
WAN Up	<input checked="" type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
WAN Down	<input checked="" type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
VPN Up	<input checked="" type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
VPN Down	<input checked="" type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>

Figure 4-3-6-2

Event Settings	
Item	Description
Enable	Check to enable "Events Settings".
Cellular Up	Cellular network is connected.
Cellular Down	Cellular network is disconnected.
WAN Up	Ethernet cable is connected to WAN port.
WAN Down	Ethernet cable is disconnected to WAN port.
VPN Up	VPN is connected.
VPN Down	VPN is disconnected.
Record	The relevant content of event alarm will be recorded on "Event" page if this option is checked.
Email	The relevant content of event alarm will be sent out via email if this option is checked.

Email Setting	Click and you will be redirected to the page "SMTP" to configure the sender's & recipients' info.
SMS	The relevant content of event alarm will be sent out via SMS if this option is checked.
SMS Setting	Click and you will be redirected to the page of "Phone" to configure phone group list.
Phone Group List	Select phone group to receive SMS alarm.

Table 4-3-6-2 Events Parameters

Related Topics

[Email Setting](#)

[Events Application Example](#)

4.5 Industrial Interface

The UG87-LW is capable of connecting with terminals through industrial interface so as to realize wireless communication between terminals and remote data center.

There are two types of the gateway's industrial interface: serial port RS232 and I/O(digital input and digital output).




Figure 4-5-1 Pinouts

PIN	RS232	DI	DO	Description
1	TXD	---	---	Transmit Data
2	RXD	---	---	Receive Data
3	---	---	---	Data +
4	---	---	---	Data-
5	GND	GND	---	Ground
6	---	IN1	---	Digital Input1
7	---	IN2	---	Digital Input2
8	---	---	OUT1	Digital Output1
9	---	---	OUT2	Digital Output2
10	---	---	COM	Common Ground

Table 4-5-1 Pinouts Definition

RS232 adopts full-duplex communication. It's generally used for communication within 20 m. Digital input of I/O interface is a logical variable or switch variable with only two values of 0 and 1. "0" refers to low level and "1" refers to high level .

4.5.1 I/O

4.5.1.1 DI

This section explains how to configure monitoring condition on digital input, and take certain actions once the condition is reached.




Figure 4-5-1-1

DI	
Item	Description
Enable	Enable or disable DI.
Mode	Options are "High Level", "Low Level", and "Counter".
Duration (ms)	Set the duration of high/low level in digital input. Range: 1-10000.
Condition	Select from "Low->High", and "High-> Low".
Low->High	The counter value will increase by 1 if digital input's status changes from low level to high level.
High->Low	The counter value will increase by 1 if digital input's status changes from high level to low level.
Counter	The system will take actions accordingly when the counter value reach the preset one, and then reset the counter value to 0. Range: 1-100.
Action	Select the corresponding actions that the system will take when digital input mode meets the preset condition or duration.
SMS	Check to enable SMS alarm.
Phone	Set phone number to receive SMS alarm.
Content	Set the content of SMS alarm.
Email	Check to enable Email alarm.
DO1	Control output status of DO1.
DO2	Control output status of DO2.
Cellular UP	Trigger the gateway to switch from offline mode to cellular network mode.

Table 4-5-1-1 DI Parameters

Related Topics

[DO Setting](#)

[Email Setting](#)

[Connect on Demand](#)

4.5.1.2 DO

This section describes how to configure digital output mode.




Figure 4-5-1-2

DO	
Item	Description
Enable	Enable or disable DO.
Mode	Select from "High Level", "Low Level", and "Pulse".
Duration (*10ms)	Set duration of high/low level on digital output. Range: 1-10000.
Initial Status	Select high level or low level as the initial status of the pulse.
Duration of High Level (*10ms)	Set the duration of pulse's high level. Range: 1-10000.
Duration of Low Level (*10ms)	Set the duration of pulse's low level. Range: 1-10000.
The Number of Pulse	Set the quantity of pulse. Range: 1-100.
Alarm Source	Select alarm source between "DI1" and "DI2".

Table 4-5-1-2 DO Settings

4.5.2 Serial Port

Serial 1 is used for RS232.

This section explains how to configure serial port parameters to achieve communication with serial terminals, and configure work mode to achieve communication with the remote data center, so as to achieve two-way communication between serial terminals and remote data center.




Figure 4-5-2-1

Serial Settings		
Item	Description	Default
Enable	Enable or disable serial port function.	Disable
Serial Type	RS232	--
Baud Rate	Range is 300-230400. Same with the baud rate of the connected terminal device.	9600
Data Bits	Options are "8" and "7". Same with the data bits of the connected terminal device.	8
Stop Bits	Options are "1" and "2". Same with the stop bits of the connected terminal device.	1
Parity	Options are "None", "Odd" and "Even". Same with the parity of the connected terminal device.	None
Software Flow Control	Enable or disable software flow control.	Disable
Serial Mode	The option is "DTU Mode". The serial port can establish communication with the remote server/client.	DTU Mode

Table 4-5-2-1 Serial Parameters

Serial Mode	DTU Mode	
DTU Protocol	Transparent	
Protocol	TCP	
Keepalive Interval	75	s
Keepalive Retry Times	9	
Packet Size	1024	Bytes
Serial Frame Interval	100	ms
Reconnect Interval	10	s
Specific Protocol	<input type="checkbox"/>	
Register String		

Destination IP Address

Server Address	Server Port	Status	Operation
			+

Figure 4-5-2-2

DTU Mode		
Item	Description	Default
DTU Protocol	Select from "None", "Transparent", "Modbus", and "TCP server". <ul style="list-style-type: none"> - Transparent: the routed is used as TCP client/UDP and transmits data transparently. - TCP server: the gateway is used as TCP server and transmits data transparently. - Modbus: the gateway will be used as TCP server with modbus gateway function, which can achieve conversion between Modbus RTU and Modbus TCP. 	--
TCP Server		
Listening port	Set the gateway listening port. Range: 1-65535.	502
Keepalive Interval	After TCP connection is established, gateway will send heartbeat packet to the client regularly by TCP to keep alive. The interval range is 1-3600 in seconds.	75
Keepalive Retry Times	When TCP heartbeat times out, gateway will resend heartbeat. After it reaches the preset retry times, TCP connection will be reestablished. The retry times range is 1-16.	9
Packet Size	Set the size of the serial data frame. Packet will be sent out when preset frame size is reached. The size range is 1-1024. The unit is byte.	1024
Serial Frame Interval	The interval that the gateway sends out real serial data stored in the buffer area to public network. The range is 10-65535, in milliseconds. Note: data will be sent out to public network when real serial data size reaches the preset packet size, even though it's within	100

	the serial frame interval.	
--	----------------------------	--

Table 4-5-2-2 DTU Parameters

Item	Description	Default
Transparent		
Protocol	Select "TCP" or "UDP" protocol.	TCP
Keepalive Interval (s)	After TCP client is connected with TCP server, the client will send heartbeat packet by TCP regularly to keep alive. The interval range is 1-3600, in seconds.	75
Keepalive Retry Times	When TCP heartbeat times out, the gateway will resend heartbeat. After it reaches the preset retry times, gateway will reconnect to TCP server. The range is 1-16.	9
Packet Size	Set the size of the serial data frame. Packet will be sent out when preset frame size is reached. The range is 1-1024. The unit is byte.	1024
Serial Frame Interval	The interval that the gateway sends out real serial data stored in the buffer area to public network. The range is 10-65535, in milliseconds. Note: data will be sent out to public network when real serial data size reaches the preset packet size, even though it's within the serial frame interval.	100
Reconnect Interval	After connection failure, gateway will reconnect to the server at the preset interval, in seconds. The range is 10-60.	10
Specific Protocol	By Specific Protocol, the gateway will be able to connect to the TCP2COM software.	--
Heartbeat Interval	By Specific Protocol, the gateway will send heartbeat packet to the server regularly to keep alive. The interval range is 1-3600, in seconds.	30
ID	Define unique ID of each gateway. No longer than 63 characters without space character.	--
Register String	Define register string for connection with the server.	Null
Server Address	Fill in the TCP or UDP server address (IP/domain name).	Null
Server Port	Fill in the TCP or UDP server port. Range: 1-65535.	Null
Status	Show the connection status between the gateway and the server.	--
Modbus		
Local Port	Set the gateway listening port. Range: 1-65535.	502

Table 4-5-2-3 DTU Parameters

Related Configuration Example

[DTU Application Example](#)

4.5.3 Modbus Master

UG87-LW can be set as Modbus Master to poll the remote Modbus Slave and send alarm according to the response.

4.5.3.1 Modbus Master

You can configure Modbus Master's parameters on this page.

Figure 4-5-3-1

Modbus Master		
Item	Description	Default
Enable	Enable/disable Modbus master.	--
Read Interval/s	Set the interval for reading remote channels. When the read cycle ends, the commands which haven't been sent out will be discard, and the new read cycle begins. If it is set to 0, the device will restart the new read cycle after all channels have been read. Range: 0-600.	0
Max. Retries	Set the maximum retry times after it fails to read, range: 0-5.	3
Max. Response Time/ms	Set the maximum response time that the gateway waits for the response to the command. If the device does not get a response after the maximum response time, it's determined that the command has timed out. Range: 10-1000.	500
Execution Interval/ms	The execution interval between each command. Range: 10-1000.	50

Table 4-5-3-1

4.5.3.2 Channel

You can add the channels and configure alarm setting on this page, so as to connect the gateway to the remote Modbus Slave to poll the address on this page and receive alarms

from the gateway in different conditions.




Figure 4-5-3-2

Channel Setting	
Item	Description
Name	Set the name to identify the remote channel. It cannot be blank.
Slave ID	Set Modbus slave ID.
Address	The starting address for reading.
Number	The address number for reading.
Type	Read command, options are "Coil", "Discrete", "Holding Register (INT16)", "Input Register (INT16)", "Holding Register (INT32)" and "Holding Register (Float)".
Link	Select TCP for transportation.
IP address	Fill in the IP address of the remote Modbus device.
Port	Fill in the port of the remote Modbus device.
Sign	To identify whether this channel is signed. Default: Unsigned.

Table 4-5-3-2




Figure 4-5-3-3

Alarm Setting	
Item	Description
Name	Set the same name with the channel name to identify the remote channel.
Condition	The condition that triggers alert.
Min. Threshold	Set the min. value to trigger the alert. When the actual value is less than this value, the alarm will be triggered.
Max. Threshold	Set the max. value to trigger the alert. When the actual value is more than this value, the alarm will be triggered.
Alarm	Select the alarm method, e.g SMS.
SMS	The preset alarm content will be sent to the specified phone number.
Phone Group	Select the phone group to receive the alarm SMS.
Normal Content	When the actual value is restored to the normal value from exceeding the threshold value, the gateway will automatically cancel the abnormal alarm and send the preset normal content to the specified phone group.
Abnormal Content	When the actual value exceeds the preset threshold, the gateway will automatically trigger the alarm and send the preset abnormal content to the specified phone group.
Continuous Alarm	Once it is enabled, the same alarm will be continuously reported. Otherwise, the same alarm will be reported only one time.

Table 4-5-3-3

4.6 Maintenance

This section describes system maintenance tools and management.

4.6.1 Tools

Troubleshooting tools includes ping and traceroute.

4.6.1.1 Ping

Ping tool is engineered to ping outer network.




Figure 4-6-1-1

PING	
Item	Description
Host	Ping outer network from the gateway.

Table 4-6-1-1 IP Ping Parameters

4.6.1.2 Traceroute

Traceroute tool is used for troubleshooting network routing failures.




Figure 4-6-1-2

Traceroute	
Item	Description
Host	Address of the destination host to be detected.

Table 4-6-1-2 Traceroute Parameters

4.6.2 Schedule

This section explains how to configure scheduled reboot on the gateway.




Figure 4-6-2-1

Schedule	
Item	Description
Schedule	Select schedule type.
Reboot	Reboot the gateway regularly.
Frequency	Select the frequency to execute the schedule.
Hour & Minute	Select the time to execute the schedule.

Table 4-5-2-1 Schedule Parameters

Related Configuration Example

[Schedule Application Example](#)

4.6.3 Log

The system log contains a record of informational, error and warning events that indicates how the system processes. By reviewing the data contained in the log, an administrator or user troubleshooting the system can identify the cause of a problem or whether the system processes are loading successfully. Remote log server is feasible, and gateway will upload all system logs to remote log server such as Syslog Watcher.

Related Configuration Example

[Logs and Diagnostics](#)

4.5.3.1 System Log

This section describes how to download log file and view the recent log on web.




Figure 4-6-3-1

System Log	
Item	Description
Download	Download log file.
View recent (lines)	View the specified lines of system log.
Clear Log	Clear the current system log.

Table 4-6-3-1 System Log Parameters

4.6.3.2 Log Settings

This section explains how to enable remote log server and local log setting.

Figure 4-6-3-2

Log Settings	
Item	Description
Remote Log Server	
Enable	With “Remote Log Server” enabled, gateway will send all system logs to the remote server.
Syslog Server Address	Fill in the remote system log server address (IP/domain name).
Port	Fill in the remote system log server port.
Local Log File	
Storage	User can store the log file in memory or TF card.
Size	Set the size of the log file to be stored.
Log Severity	The list of severities follows the syslog protocol.

Table 4-6-3-2 System Log Parameters

4.6.4 Upgrade

This section describes how to upgrade the gateway firmware via web. Generally you don't need to do the firmware upgrade.

Note: any operation on web page is not allowed during firmware upgrade, otherwise the upgrade will be interrupted, or even the device will break down.




Figure 4-6-4-1

Upgrade	
Item	Description
Firmware Version	Show the current firmware version.
Reset Configuration to Factory Default	When this option is checked, the gateway will be reset to factory defaults after upgrade.
Upgrade Firmware	Click "Browse" button to select the new firmware file, and click "Upgrade" to upgrade firmware.

Table 4-5-4-1 Upgrade Parameters

Related Configuration Example

[Firmware Upgrade](#)

4.6.5 Backup and Restore

This section explains how to create a complete backup of the system configurations to a file, restore the config file to the gateway and reset to factory defaults.




Figure 4-6-5-1

Backup and Restore	
Item	Description
Config File	Click "Browse" button to select configuration file, and then click "Import" button to upload the configuration file to the gateway.
Backup	Click "Backup" to export the current configuration file to the PC.
Reset	Click "Reset" button to reset factory default settings. gateway will restart after reset process is done.

Table 4-5-5-1 Backup and Restore Parameters

Related Configuration Example

[Backup and Restore Configuration](#)

[Restore Factory Defaults](#)

4.6.6 Reboot

On this page you can reboot the gateway and return to the login page. We strongly recommend clicking “Save” button before rebooting the gateway so as to avoid losing the new configuration.




Figure 4-5-6-1

4.7 APP

4.7.1 Python

Python is an object-oriented programming language that has gained popularity because of its clear syntax and readability.

As an interpreted language, Python has a design philosophy that emphasizes code readability, notably using whitespace indentation to delimit code blocks rather than curly brackets or keywords, and a syntax that allows programmers to express concepts in fewer lines of code than it's used in other languages such as C++ or Java. The language provides constructs and intends to enable writing clear programs on both small and large scale.

Users can use Python to quickly generate the prototype of the program, which can be the final interface of the program, rewrite it with a more appropriate language, and then encapsulate the extended class library that Python can call.

This section describes how to view the relevant running status such as App-manager, SDK version, extended storage, etc. Also you can change the App-manager configuration, and import the Python App package from here.

4.7.1.1 Python




Figure 4-7-1-1

Python	
Item	Description
AppManager Status	Show AppManager's running status, like "Uninstalled", "Running" or "Stopped".
SDK Version	Show the version of the installed SDK.
SDK Path	Show the SDK installation path.
Available Storage	Select available storage such as Micro SD or SSD to install SDK.
SDK Upload	Upload and install SDK for Python.
Uninstall	Uninstall SDK.
View	View application status managed by AppManager.

Table 4-7-1-1 Python Parameters

4.7.1.2 App Manager Configuration




Figure 4-7-1-2

AppManager Configuration	
Item	Description

Enable	After enabling Python AppManager, user can click "View" button on the "Python" webpage to view the application status managed by AppManager.
App Management	
ID	Show the ID of the imported App.
App Command	Show the name of the imported App.
Logfile Size(MB)	User-defined Logfile size. Range: 1-50.
Uninstall	Uninstall APP.
App Status	
App Name	Show the name of the imported App.
App Version	Show the version of the imported App.
SDK Version	Show the SDK version which the imported App is based on.

Table 4-7-1-2 APP Manager Parameters

4.7.1.3 Python App

Figure 4-7-1-3

Python APP	
Item	Description
App Package	Select App package and import.
App Name	Select App to import configuration.
App Configuration	Select configuration file and import.
Debug File	Export script file.
Debug Script	Select Python script to be debugged and import.

Table 4-7-1-3 APP Parameters


Chapter 5 Application Examples

5.1 Application configuration

You can create a new application on this page, mainly used for defining the method to decode the data sent from end-device.

The configuration procedures are listed as below.

1. Go to “LoRaWAN” > “Network Server” > “Application”.

2. Click  to enter the configuration page, as the following picture shows:

The screenshot shows the 'Applications' configuration page. It includes the following elements:

- General** | **Applications** | Profiles | Device | Packets
- Applications** section:

 - Name: Ursalink-app
 - Description: a application for ursalink test
 - Payload Codec: Custom

- Payload decoder function** code block:

```
// Decode decodes an array of bytes into an object.
// - fPort contains the LoRaWAN fPort number
// - bytes is an array of bytes, e.g. [225, 230, 255, 0]
// The function must return an object, e.g. {"temperature": 22.5}
function Decode(fPort, bytes) {
  return {};
}
```
- Payload encoder function** code block:

```
// Encode encodes the given object into an array of bytes.
// - fPort contains the LoRaWAN fPort number
// - obj is an object, e.g. {"temperature": 22.5}
// The function must return an array of bytes, e.g. [225, 230, 255, 0]
function Encode(fPort, obj) {
  return [];
}
```
- Buttons: Save, Cancel

Application Configuration		
Item	Description	Default
Name	Enter the name of the application profile. E.g Smoker-sensor-app.	
Description	Enter the description of this application. E.g a application for smoker sensor.	
Payload Codec	Select from: “None”, “Cayenne LPP”, “Custom”. None: This mode enables devices not to encode data. Cayenne LPP: This mode enables devices to encode data with the Cayenne Low Power Payload (LPP). Custom: This mode enables devices to encode data with the decoder function and the encoder function which you have entered the code.	None

5.2 Device Profiles Configuration

Device Profiles

Name

Max TXPower

Join Type

Class Type


Advanced

MAC Version

Regional Parameters Revision

Device Profiles Setting		
Item	Description	Default
Name	Enter the Name of the application profile. E.g. Smoker-sensor-app.	Null
Max TXPower	Enter the maximum transmit power. 0 means using the max EIRP.	0. The TXPower indicates power levels relative to the Max EIRP level of the end-device. 0 means using the max EIRP. EIRP refers to the Equivalent Isotropically Radiated Power.
Join Type	Select from: "OTAA" and "ABP". OTAA:Over-the-Air Activation. For over-the-air activation, end-devices must follow a join procedure prior to participating in data exchanges with the network server. An end-device has to go through a new join procedure every time it has lost the session context information. ABP: Activation by Personalization. Under certain circumstances, end-devices can be activated by personalization. Activation by personalization directly ties an end-device to a specific network by-passing the join request - join	OTAA

	accept procedure.	
Class Type	<p>Select from: "A" and "C".</p> <p>A: Class A operation is the lowest power end-device system for applications that only require downlink communication from the server shortly after the end-device has sent an uplink transmission.</p> <p>C: End-device of Class C have nearly continuously open receive windows, only closed when transmitting. Class C end-device will use more power to operate than Class A or Class B but they offer the lowest latency for server to end-device communication.</p>	A

Check **Advanced**  to show the advanced settings.

Device Profile Advanced Settings		
Item	Description	Default
MAC Version	Choose the Version of the LoRaWAN supported by the end-device.	1.0.2
Regional Parameter Revision	Revision of the Regional Parameters document supported by the end-device.	B
RX1 Datarate Offset	Enter the offset which used for calculate the RX1 data-rate, based on the uplink data-rate. The range is based on what is specified in the LoRaWAN regional parameters document.	The default offset is based on what is specified in the LoRaWAN regional parameters document.
RX2 Datarate	Enter the RX2 datarate which used for the RX2 receive-window. The range is based on what is specified in the LoRaWAN regional parameters document.	The default offset is based on what is specified in the LoRaWAN regional parameters document.
RX2 Channel Frequency	Enter the RX2 channel frequency which used for the RX2 receive-window. The range is based on what is specified in the LoRaWAN regional parameters document.	Null
Frequency List	List of factory-preset frequencies. The range is based on what is specified in the LoRaWAN regional parameters document.	Null

ACK Timeout	Enter the time for confirmed downlink transmissions. Only class C.	5
-------------	--	---

5.3 Device Configuration

Go to “LoRaWAN” > “Network Server” > “Device”

You can edit the device configuration by clicking  or create a new device by clicking , as shown:

Device

General

Device Name

Description

Device EUI

Device-Profile

Application

Frame-counter Validation

Device Configuration-General		
Item	Description	Default
Device	Enter the name of this device.	Null
Description	Enter the description of this device.	Null
Device EUI	Enter the EUI of this device.	Null
Device-Profile	Choose the device profile from created device profiles.	Null
Application	Choose the application profile from created application.	Null
Frame-Counter Validation	If disable the frame-counter validation, it will compromise security as it enables people to perform replay-attacks.	Enabled

Activate Device(ABP)


Device Address

Network Session Key

Application Session Key

Uplink Frame-counter

Downlink Frame-counter



ABP stands for Authentication By Personalisation. It means that the encryption keys are configured manually on the device and can start sending frames to the Gateway without needing a 'handshake' procedure to exchange the keys (such as the one performed during an OTAA join procedure).

With ABP the encryption keys enabling communication with the network are preconfigured in the device. The network will need to provide you with a Device Address, Network Session Key and Application Session Key.

Device Configuration-Activate Device-ABP		
Item	Description	Default
Device Address	Enter the device address. The device address identifies the end-device within the current network.	Null
Network Session Key	Enter the network session key of the device. The network session key specific for the end-device. It is used by the end-device to calculate the MIC or part of the MIC (message integrity code) of all uplink data messages to ensure data integrity.	Null
Application Session Key	Enter the application session key of the device. The AppSKey is an application session key specific for the end-device. It is used by both the application server and the end-device to encrypt and decrypt the payload field of application-specific data messages.	Null
Uplink Frame-counter	The number of data frames which sent uplink to the network server. It will be incremented by the end-device and received by the end-device. Users can reset the a personalized end-device manually, then the frame counters on the end-device and the frame counters on the network server for that end-device will be reset to 0.	Null
Downlink Frame-counter	The number of data frames which received by the end-device downlink from the network server. It will be incremented by the network server.	Null

	Users cloud reset the a personalized end-device manually, then the frame counters on the end-device and the frame counters on the network server for that end-device will be reset to 0.	
--	--	--

Activate Device(OTAA)

Application Key


Device Address

Network Session Key

Application Session Key

Uplink Frame-counter

Downlink Frame-counter



OTAA stands for Over The Air Activation. With this method the end-device sends a Join request to the gateway using the Application Key, Application Key is a shared secret key unique to your device to generate the session keys that prove its identity to the network. If the keys are correct, the gateway will reply to the end-device with a join accept message, and from that point on the end-device is able to send and receive packets to/from gateway. If the keys are incorrect, no response will be received.

Device Configuration-Activate Device-OTAA		
Item	Description	Default
Application Key	Enter the application key. Whenever an end-device joins a network via over-the-air activation, the application key is used for derive the Application Session key.	Null
Device Address	Show the device address when the device has been activated. The device address identifies the end-device within the current network.It will be cleared when the node has not been activated yet or device has been inactive for a long time.	Null
Network Session Key	Show the network session key of the device when the device has been activated. The network session key specific for the end-device. It is used by the end-device to calculate	Null

	the MIC or part of the MIC (message integrity code) of all uplink data messages to ensure data integrity. It will be cleared when the node has not been activated yet or device has been inactive for a long time.	
Application Session Key	Show the application session key of the device when the device has been activated. The AppSKey is an application session key specific for the end-device. It is used by both the application server and the end-device to encrypt and decrypt the payload field of application-specific data messages. It will be cleared when the node has not been activated yet or device has been inactive for a long time.	Null
Uplink Frame-counter	The number of data frames which sent uplink to the network server. It will be incremented and received by the end-device. After a JoinReq -JoinAccept message exchange, the frame counters on the end-device and the frame counters on the network server for that end-device will be reset to 0.	Null
Downlink Frame-counter	The number of data frames which received by the end-device downlink from the network server. It will be incremented by the network server. After a JoinReq -JoinAccept message exchange, the frame counters on the end-device and the frame counters on the network server for that end-device will be reset to 0.	Null

5.4 Account Info Management

It is strongly recommended that you change the default username and password of the administrator account when you log in Ursalink gateway's WEB GUI page at first time for the sake of security.

Example: change the username and password of administrator account to "uradmin" and "URpassword".

The configuration procedures are listed as below.

1. Go to "System > User Management> Account".
2. Modify the username to "uradmin", fill in the old Password "password", and set the new Password "URpassword".

Click "Save" button, and then you will be asked to login again with the new username and password.

The screenshot shows the 'User Management' section of the interface. Under the 'Account' tab, there is a 'Change Account Info' form. The form contains the following fields:

- Username: admin
- Old Password: [password field]
- New Password: [password field]
- Confirm New Password: [password field]

A blue 'Save' button is located at the bottom of the form.

Related Topic

[Account Management](#)

5.5 Common User Management

The UG87-LW is capable of creating up to 5 common user accounts that have different authorities, including “Read-Only” and “Read-Write” to manage the gateway.

“Read-Only” refers to the authority that user is only allowed to view the configuration;

“Read-Write” refers to the authority that user can view and modify all the parameters.

Example: create 2 common user accounts listed below.

Username	Password	Permission
ur_user1	UR_password1	Read-Only
ur_user2	UR_password2	Read-Write

Configuration procedures are listed as blow.

1. Go to “System > User Management > User Management”.
2. Click “+” to add a new common user.
3. Set “Username”, “Password”, and “Permission” as below.

The screenshot shows the 'User Management' section of the interface. Under the 'User Management' tab, there is a 'User List' table. The table has the following columns: Username, Password, Permission, and Operation. Two users are listed:

Username	Password	Permission	Operation
test1	*****	Read-Only	[X]
test2	*****	Read-Write	[X]

A blue 'Save' button is located at the bottom of the table.

Click “Save” button, and then click “Apply” on the top-right corner to make the changes take effect.

Related Topic

[User Management](#)

5.6 System Time Management

There are 3 ways to synchronize the system time: “Sync with Browser”, “Set up Manually”, and “Sync with NTP Server”.

Note: to ensure that the gateway runs with correct time, it’s recommended that you set the system time when you configure the gateway.

In the following part we take UTC+8 time zone as an example.

A. Synchronize time with browser

Go to “System > General Settings > System Time”, set time zone as “8 China (Beijing)” and Sync Type as “Sync with Browser”. And Click “Save” button.

The screenshot shows the 'System Time Settings' page. The 'Current Time' is 2017-11-09 09:17:40 Thur. The 'Time Zone' is set to '8 China (Beijing)' and the 'Sync Type' is 'Sync with Browser'. The 'Browser Time' is 2017-11-09 09:18:29 Thur. A blue 'Save' button is at the bottom. A circled '1' points to the dropdown menus for Time Zone and Sync Type, and a circled '2' points to the Save button.

B. Set up time by manual

1. Go to “System > General Settings > System Time”, set time zone as “8 China (Beijing)” and Sync Type as “Set up Manually”.
2. Select the correct local time. And click “Save” button.

The screenshot shows the 'System Time Settings' page. The 'Current Time' is 2017-11-09 09:18:16 Thur. The 'Time Zone' is '8 China (Beijing)' and the 'Sync Type' is 'Set up Manually'. The 'Date' is 2017-11-09 and the 'Time' is 9:19:04. A blue 'Save' button is at the bottom. A circled '1' points to the dropdown menus for Time Zone and Sync Type, a circled '2' points to the Date and Time fields, and a circled '3' points to the Save button.

C. Synchronize time with NTP server

1. Go to “System > General Settings > System Time”, set time zone as “8 China (Beijing)” and Sync Type as “Sync with NTP Server”.

2. Configure an available NTP server address such as “time.windows.com”.
Click “Save” button.

System Time Settings

Current Time: 2017-11-09 09:19:27 Thur

Time Zone: 8 China (Beijing) (1)

Sync Type: Sync with NTP Server (1)

NTP Server Address: time.windows.com (2)

Enable NTP Server:

Save (3)

Related Topic

[System Time Setting](#)

5.7 Backup and Restore Configuration

A. Backup Configuration

1. Go to “Maintenance > Backup and Restore > Backup and Restore”.
2. Click “Backup” button under “Backup running-config”.

Then the current configuration file will be downloaded to the “Downloads” folder of the PC.

Backup and Restore (1)

Backup and Restore (2)

Restore Config

Config File: Browse Import

Backup Running-config


Backup (3)

Restore Factory Defaults

Reset

B. Restore Configuration

1. Go to “Maintenance > Backup and Restore > Backup and Restore”.
2. Click “Browse” button under the “Restore” to select configuration file from PC.
3. Click “Import” to import the selected configuration file to the gateway.



Related Topic



[Backup and Restore](#)

5.8 Restore Factory Defaults


5.8.1 Via Web Interface

1. Log in web interface, and go to “Maintenance > Backup and Restore”.
2. Click “Reset” button under the “Restore Factory Defaults”.


You will be asked to confirm if you’d like to reset it to factory defaults. Then click “Reset” button.



Then the gateway will reboot and restore to factory settings immediately.



Please wait till the login page pops up again, which means the gateway has already been reset to factory defaults successfully.



Related Topic

[Restore Factory Defaults](#)

5.8.2 Via Hardware



Locate the reset button on the gateway, and take corresponding actions based on the status of STATS LED.




STATUS LED	Action
Blinking	Press and hold the reset button for more than 15 seconds.
Static Green → Rapidly Blinking	Release the button and wait.
Off → Blinking	The gateway is now reset to factory defaults.

5.9 Firmware Upgrade

It is suggested that you contact Ursalink technical support first before you upgrade gateway firmware.

After getting firmware file from Ursalink technical support, please refer to the following steps to complete the upgrade.

1. Go to “Maintenance > Upgrade”.
2. Click “Browse” and select the correct firmware file from the PC.
3. Click “Upgrade” and the gateway will check if the firmware file is correct. If it’s correct, the firmware will be imported to the gateway, and then the gateway will start to upgrade.



Related Topic

[Upgrade](#)

5.10 Events Application Example

Example

In this section, we will take an example of sending alarm messages by email when the following events occur and recording the event alarms on the Web GUI.

Events	Actions to make events occur (for test)
Cellular network is connected.	Insert SIM card.
Cellular network is disconnected.	Remove SIM card.
WAN cable is connected.	Plug WAN cable.
WAN cable is disconnected.	Unplug WAN cable.



Configuration Steps

1. Go to “System > Events > Events Settings” and enable Event settings.
2. Check corresponding events for record and email alarm, and then click “Save” button as below. Click “Email Settings” and go to SMTP settings.


The screenshot displays the 'Events Settings' configuration page. On the left sidebar, 'Events' is selected (1). The main content area shows the 'Events Settings' section (2). The 'Enable' checkbox is checked (3). Below it are dropdown menus for 'Phone Group List' and 'Email Group List'. A table lists various events with columns for 'Record', 'Email Email Setting' (6), and 'SMS SMS Setting'. A blue box highlights the 'Record' and 'Email Email Setting' columns for Cellular Up, Cellular Down, WAN Up, and WAN Down events (4). A 'Save' button (5) is located at the bottom of the page.

Events	Record	Email Email Setting (6)	SMS SMS Setting
Cellular Up	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>
Cellular Down	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>
WAN Up	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>
WAN Down	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>
VPN Up	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
VPN Down	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>

Configure the corresponding parameters including email sending settings and recipients as below. Click “Save” and “Apply” button to make the changes take effect.



- To test the functionality of Alarm, please take the corresponding actions listed above. It will send an alarm e-mail to you when the relevant event occurs. Refresh the web GUI, go to “Events > Events”, and you will find the events records.



Related Topics

[Events](#)

[Email Setting](#)

5.11 Schedule Application Example


Through schedule configuration, the UG87-LW can be set to reboot at preset time every day.

Example

Configure gateway to reboot at 0:00 every day.

Configuration Steps

1. Go to “Maintenance > Schedule > Schedule”.
2. Click “+” to set up a new schedule task as below.
3. Click “Save” and “Apply” button.



Related Topic

[Schedule Setting](#)

5.12 Logs and Diagnostics

System log of the UG87-LW supports 2 types of output method, including Web, Remote Log Server and Console.

Application 1

Obtain system log on Web.

Go to “Maintenance > Log > System log”, and you will see the log is listed in the box.

Application 2

Send the system log to the remote syslog server.

Server IP: 110.22.14.43; Port: 514

Go to “Maintenance > Log > Log Settings” to configure the parameters as below.

Then click “Save” and “Apply” button.


Related Topic

[System Log](#)


5.13 SNMP Application Example

Before you configure SNMP parameters, please download the relevant “MIB” file from the UG87-LW’s WEB GUI first, and then upload it to any software or tool which supports standard SNMP protocol. Here we take “ManageEngine MibBrowser Free Tool” as an example to access the gateway to query cellular information.


1. Go to “System > SNMP > MIB” and download the MIB file “URSA-gateway-MIB.txt” to PC.




2. Start “ManageEngine MibBrowser Free Tool” on the PC. Click “File > Load MIB” on the menu bar. Then select “BURSA-gateway-MIB.txt” file from PC and upload it to the software.




Click the “+” button beside “URSA-gateway-MIB”, which is under the “Loaded MibModules” menu, and find “usCellularinfo”. And then you will see the OID of cellular info is “1.3.6.1.4.1.50234”, which will be filled in the MIB View settings.




- Go to “System > SNMP > SNMP” on the gateway’s WEB GUI. Check “Enable” option, then click “Save” button.



- Go to “System > SNMP > MIB View”. Click  to add a new MIB view and define the view to be accessed from the outside network. Then click “Save” button.



5. Go to “System > SNMP > VACM”. Click to add a new VACM setting to define the access authority for the specified view from the specified outside network. Click “Save” and “Apply” to make the changes take effect.



6. Go to MibBrowser, enter host IP address, port and community. Right click “usCellular CurrentSim” and then click “GET”. Then you will get the current SIM info on the result box. You can get other cellular info in the same way.

The screenshot shows the ManageEngine MibBrowser Free Tool interface. On the left, a tree view displays the MIB structure under 'URSA-ROUTER-MIB' > 'enterprises' > 'ursa' > 'usManage'. The 'usCellularCurrentSim' MIB is selected and highlighted with a blue circle containing the number 17. The right panel shows the configuration for this MIB, including Host (192.168.1.1), Port (161), and Community (public). Below the configuration, a status window displays the following information:

```

MIB(s) Loaded Successfully..
Sent GET request to 192.168.1.1 : 161
Request Failed: Get Response PDU received from 192.168.1.1 Error Indication in
response: There is no such variable name in this mib. Errindex: 1
usCellularCurrentSim.0 1 result

```

Description	Multi Var	Status	Reference
Syntax	OCTET STRING	current	
Access	read-only		
Index			
Object ID	. 1. 3. 6. 1. 4. 1. 50234. 1. 6. 1		
Description	"Description."		

Related Topic

[SNMP](#)

5.14 Cellular Connection



The UG87-LWs have two cellular interfaces, named SIM1 & SIM2. Only one cellular interface is active at one time. If both cellular interfaces are enabled, SIM1 interface takes precedence as default.

Example

We are about to take an example of inserting a SIM card into SIM1 slot of the UG87-LW and configuring the gateway to get Internet access through cellular.

Configuration Steps

1. Go to "Network > Interface > Cellular > Cellular Setting" and configure the cellular info.
2. Enable SIM1.
3. Choose relevant network type. "Auto", "4G First", "4G Only", "3G First", "3G Only", "2G First" and "2G only" are optional.



Click “Save” and “Apply” for configuration to take effect.

Note:

If you select “Auto”, the gateway will obtain ISP information from SIM card to set APN, Username, and Password automatically. This option will only be taken effect when the SIM card is issued from well-known ISP.

If you select “4G First” or “4G Only”, you can click “Save” to finish the configuration directly.

If you select “3G First”, “3G Only”, “2G First” or “2G Only”, you should manually configure APN, Username, Password, and Access Number.

4. Check the cellular connection status by WEB GUI of gateway.

Click “Status > Cellular” to view the status of the cellular connection. If it shows 'Connected',

SIM1 has dialed up successfully.

Overview	Cellular	Network	WLAN	VPN	Routing	Host List	GPS
Modem							
Status	Ready						
Model	U9300C						
Current SIM	SIM1						
Signal Level	29asu (-56dBm)						
Register Status	Registered (Home network)						
IMSI	460070615219248						
ICCID	898602E6131532019248						
ISP	CHINA MOBILE						
Network Type	LTE						
PLMN ID	46007						
LAC	fffe						
Cell ID	f700e28						
IMEI	862808032459987						
Network							
Status	Connected						
IP Address	10.39.128.14						
Netmask	255.255.255.252						
Gateway	10.39.128.13						
DNS	211.143.147.120						
Connection Duration	0 days, 00:15:35						
							Manual Refresh
							Refresh

5. Check out if network works properly by browser on PC.

Open your preferred browser on PC, type any available web address into address bar and see if it is able to visit Internet via the UG87-LW.

Related Topic

[Cellular Setting](#)

[Cellular Status](#)


5.15 Dual SIM Backup Application Example

Example


In this section we will take an example of inserting two SIM cards into the UG87-LW. When one SIM fails, gateway will try to connect with the other SIM as backup link.

Configuration Steps

1. Go to “Network > Interface > Cellular” to enable SIM1 and SIM2. Leave the network type as “Auto” by default.



2. Enable “Dual SIM Strategy”, and configure the corresponding options as below. ICMP server can be configured as any reachable IP address.



Then click “Save” and “Apply” button.

3. Go to “Status > Cellular”, and you will see the gateway is connected to the network via SIM1.

Overview	Cellular	Network	VPN	Routing
Modem				
Status	Ready			
Model	EC25			
Current SIM	SIM1			
Signal Level	15asu (-83dBm)			
Register Status	Registered (Home network)			
IMSI	460019987103071			
ICCID	89860117838019196629			
ISP	CHN-UNICOM			
Network Type	LTE			

Network	
Status	Connected
IP Address	10.105.39.33

- You can remove SIM1 to make the gateway fail to connect to network via it. Go to “Status > Cellular” again, and you will see the gateway is connected to the network through SIM2.

Overview	Cellular	Network	VPN	Routing
Modem				
Status	Ready			
Model	EC25			
Current SIM	SIM2			
Signal Level	15asu (-83dBm)			
Register Status	Registered (Home network)			
IMSI	460019987103071			
ICCID	89860117838019196629			

Network	
Status	Connected
IP Address	10.63.223.44

Now SIM2 becomes the main SIM, and SIM1 runs as the backup. The gateway won't reconnect via SIM1 until SIM2 fails.

Related Topic[Cellular Setting](#)[Cellular Status](#)**5.17 NAT Application Example****Example**

An UG87-LW can access Internet via cellular. GE port is connected with a Web server whose IP address is 192.168.1.2 and port is 8000. Configure the gateway to make public network access the server.

Configuration Steps

Go to “Firewall > Port Mapping” and configure port mapping parameters.

The screenshot shows the URSALINK web interface for configuring Port Mapping. The 'Firewall' menu item is selected in the sidebar. The 'Port Mapping' configuration page is active, showing a table with the following data:

Source IP	Source Port	Destination IP	Destination Port	Protocol	Description	Operation
0.0.0.0/0	8000	192.168.1.2	8000	TCP	Server	[X] [+]

Buttons for 'Save' and 'Apply' are present at the bottom of the configuration area.


Click “Save” and “Apply” button.

Related Topic[Port Mapping](#)**5.18 Access Control Application Example****Application Example**


GE port of the UG87-LW is set as LAN with IP 192.168.1.0/24. Then configure the gateway to deny accessing to Google IP 198.98.108.64 from local device with IP 192.168.1.12.

Configuration Steps

1. Go to “Network > Firewall > ACL” to configure access control list. Click “+” button to set parameters as below. Then click “Save” button.



2. Configure interface list. Then click “Save” and “Apply” button.




Related Topic

[ACL](#)

5.18 DTU Application Example

Example


PLC is connected with the UG87-LW via RS232. Then enable DTU function of the UG87-LW to make a remote TCP server communicate with PLC. Refer to the following topological graph.




Serial Parameters of the PLC	
Baud Rate	9600
Data Bit	8
Stop Bit	1
Parity	None

Configuration Steps

1. Go to “Industrial > Serial Port” and configure serial port parameters. The serial port parameter shall be kept in consistency with those of PLC, as shown in figure below.




2. Configure Serial Mode as “DTU Mode”. The UG87-LW is connected as client in “Transparent” protocol.



3. Configure TCP server IP and port.



4. Once you complete all configurations, click “Save” and “Apply” button.

5. Start TCP server on PC.

Take “Netassist” test software as example. Make sure port mapping is already done.




6. Connect the UG87-LW to PC via RS232 for PLC simulation. Then start “sscom” software

on the PC to test communication through serial port.




7. After connection is established between the UG87-LW and the TCP server, you can send data between sscm and netassit.

PC side



TCP server side



- After serial communication test is done, you can connect PLC to RS232 port of the UG87-LW for test.


Related Topic

[Serial Port](#)

5.19 PPTP Application Example

Example


Configure the UG87-LW as PPTP client to connect to a PPTP server in order to have data transferred securely. Refer to the following topological graph.



Configuration Steps

- Go to “Network > VPN > PPTP”, configure PPTP server IP address, username and password provided by PPTP server.


Note: If you want to have all data transferred through VPN tunnel, check “Global Traffic Forwarding” option.



If you want to access peer subnet such as 192.168.3.0/24, you need to configure the subnet and mask to add the route.



2. Check “Show Advanced” option, and you will see the advanced settings.



If the PPTP server requires MPPE encryption, then you need to check “Enable MPPE” option.

Enable MPPE



If the PPTP server assigns fixed tunnel IP to the client, then you can fill in the local tunnel IP and remote tunnel IP, shown as below.

Local IP Address	205.205.0.100
Peer IP Address	205.205.0.1

Otherwise PPTP server will assign tunnel IP randomly.

Click “Save” button when you complete all settings, and then the advanced settings will be hidden again. Then click “Apply” button to have the configurations take effect.

3. Go to “Status > VPN” and check PPTP connection status.

PPTP is established as shown below.

Local IP: the client tunnel IP.

Remote IP: the server tunnel IP.

Overview Cellular Network VPN Routing Host List					
PPTP Tunnel					
Name	Status	Local IP	Remote IP		
pptp_1	Connected	120.205.0.100	205.205.0.1/32		
pptp_2	Disconnected	-	-		
pptp_3	Disconnected	-	-		

Related Topics

[PPTP Setting](#)

[PPTP Status](#)

[END]